

FOOLPROOF TARGET KNOBS - TARGET ELEVATION KNOB, SHORT

[Gunsmith Tools & Supplies](#) > [Sight & Scope Installation Tools](#) > [Replacement Sight Screws](#)

All Foolproof sights (except TK models) use the Short Elevation Knob. The Long Elevation Knob is for use with Foolproof-TK target sights. The Elevation Gib Lock Knob fits both standard Foolproof and Foolproof-TK models



Attributes

- Name: [TARGET ELEVATION KNOB, SHORT](#)
- Manufacturer: [WILLIAMS GUN SIGHT](#)
- Product no.: 962157250
- Mfr. No.: 11524
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 053506115242

Item details

Made in USA

Table of Contents

- Startpage
- FOOLPROOF TARGET KNOBS TARGET ELEVATION KNOB, SHORT Safety Instructions
- About Us

FOOLPROOF TARGET KNOBS TARGET ELEVATION KNOB, SHORT Safety Instructions

Introduction

Thank you for choosing the FOOLPROOF TARGET KNOBS TARGET ELEVATION KNOB, SHORT. This product is designed to enhance your shooting experience by providing precise elevation adjustments. However, to ensure your safety and the proper functioning of the product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure the product is used only for its intended purpose in accordance with the manufacturer's instructions.
- Inspect the product before each use to ensure it is in good condition and free from defects.
- Store the product in a dry, cool place when not in use to prevent damage.
- Be aware of your surroundings and ensure that your shooting area is safe and secure.
- Always prioritize safety when handling firearms and associated equipment.

Specific Safety Precautions for Use

- Avoid using the elevation knob with FoolproofTK target sights, as it is only compatible with standard Foolproof models.
- Ensure that the elevation knob is properly fitted to the sight before use. Improper fitting may lead to inaccurate adjustments or potential accidents.
- If you experience difficulty fitting the knob, do not force it. Seek professional assistance to ensure proper installation.
- Keep the elevation knob and all related components out of reach of children and unauthorized users.
- If you notice any unusual wear or damage, discontinue use immediately and consult a qualified technician.

Instructions for Installation and Usage

1. Installation Steps:

- Gather the necessary tools, including a screwdriver for installation.
- Remove the existing elevation knob from your sight by unscrewing it counterclockwise.
- Align the threads of the new elevation knob with the corresponding threads on the sight.
- Screw the new elevation knob onto the sight by turning it clockwise until it is securely fastened. Do not overtighten.
- If fitting issues arise, grind the tip of the threads as necessary to ensure a proper fit.

2. Usage Instructions:

- To adjust the elevation, turn the knob clockwise to raise the sight and counterclockwise to lower it.
- Make small adjustments and test the sighting after each adjustment to ensure accuracy.
- Regularly check the knob to ensure it remains securely fastened during use.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the product is no longer usable, please dispose of it in a manner that minimizes environmental impact. Consider recycling where possible.
- Ensure that any metal components are disposed of responsibly to prevent injury to wildlife and others.

Contact Information for Further Support

For any inquiries or concerns regarding the FOOLPROOF TARGET KNOBS TARGET ELEVATION KNOB, SHORT, please refer to the manufacturer's contact information provided with the product packaging or on the manufacturer's website.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your shooting experience!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at