

# 1911 "FACTORY PLUS" MAINSPRING - MAINSPRING

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainsprings](#)

## Quality Parts Meet Or Exceed Factory Specs

"Just like original" parts for building a 1911 Auto or returning a gun to factory specifications.



## Attributes

- Name: [MAINSPRING](#)
- Manufacturer: [WILSON COMBAT](#)
- Product no.: 965011160
- Mfr. No.:
- Make: 1911
- Model: Government, Commander
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 874218003005

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for 1911 "FACTORY PLUS" MAINSPRING
- About Us

# Safety Instruction Guide for 1911 "FACTORY PLUS" MAINSPRING

## Introduction

Thank you for choosing the 1911 "FACTORY PLUS" MAINSPRING. This product is designed to help you build or restore your 1911 Auto to factory specifications. To ensure your safety and the proper functioning of your firearm, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Always treat firearms with respect and caution.
- Ensure that your firearm is unloaded before handling or installing any parts.
- Keep firearms out of reach of children and unauthorized users.
- Use only parts that are compatible with your specific model of 1911 Auto.
- Regularly inspect all components for wear or damage before use.
- If you are unsure about any aspect of installation or usage, seek assistance from a qualified gunsmith.

## Specific Safety Precautions for Use

- Ensure you are in a safe environment when handling or working with firearms.
- Wear appropriate safety gear, including eye protection and gloves, when installing or handling the mainspring.
- Be aware of the potential hazards associated with the use of firearms, including accidental discharge.
- Always follow the manufacturer's instructions for your specific firearm model.
- If you experience any issues during installation, stop and consult a professional.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and a mainspring housing tool.

### 2. Installation Steps:

- Remove the grip panels from the firearm.
- Carefully remove the mainspring housing from the frame of the firearm.
- Replace the old mainspring with the new 1911 "FACTORY PLUS" MAINSPRING.
- Ensure the mainspring is seated properly in the housing.
- Reattach the mainspring housing to the frame.
- Replace the grip panels securely.

### 3. PostInstallation Check:

- Inspect the installation to ensure everything is secured properly.
- Test the action of the firearm to ensure it operates smoothly.
- Conduct a function check to verify that the firearm cycles correctly.

## Disposal Instructions

- Dispose of any old or unused parts in accordance with local regulations.
- Do not dispose of firearms or firearm parts in regular household waste.

- Contact a local waste management authority for guidance on safe disposal methods.

## Contact Information for Further Support

For any safety inquiries or concerns regarding the 1911 "FACTORY PLUS" MAINSPRING, please contact your local firearms dealer or a qualified gunsmith for assistance.

## Conclusion

By following these safety instructions, you can ensure the safe and effective use of your 1911 "FACTORY PLUS" MAINSPRING. Always prioritize safety and seek help if you are uncertain about any procedures. Thank you for your attention to these important guidelines.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)