

1911 AUTO "FACTORY PLUS" SEAR SPRINGS - SEAR SPRING

[Handgun Parts](#) > [Trigger Group Parts](#) > [Sear Parts](#) > [Sear Springs](#)

Quality Parts Meet Or Exceed Factory Specs

"Just like original" parts for building a 1911 Auto or returning a gun to factory specifications.



Attributes

- Name: [SEAR SPRING](#)
- Manufacturer: [WILSON COMBAT](#)
- Product no.: 965011290
- Mfr. No.:
- Make: 1911
- Model: Government,Commander,Officers
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 874218003166

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for 1911 AUTO "FACTORY PLUS" SEAR SPRINGS](#)
- [About Us](#)

Safety Instruction Guide for 1911 AUTO "FACTORY PLUS" SEAR SPRINGS

Introduction

Thank you for choosing the 1911 AUTO "FACTORY PLUS" SEAR SPRINGS. This product is designed to help you build or restore your 1911 Auto to factory specifications. To ensure your safety and the safe use of this product, please read and follow the instructions outlined in this guide.

General Safety Guidelines

- Ensure that all firearms are handled safely and responsibly.
- Always treat every firearm as if it is loaded.
- Store this product and any related tools out of reach of children and unauthorized users.
- Use this product only in accordance with the manufacturer's instructions.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the 1911 AUTO "FACTORY PLUS" SEAR SPRINGS with compatible models: Government, Commander, and Officers.
- Inspect all components for damage before installation. Do not use if any part is damaged or worn.
- Wear appropriate safety gear, such as safety glasses and gloves, when handling and installing the sear springs.
- Ensure the firearm is unloaded and the safety is engaged before starting any installation or maintenance work.
- Do not attempt to modify or alter the sear springs in any way.
- If you are unsure about the installation process, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure your workspace is clean and welllit.
- Gather all necessary tools, including screwdrivers and pliers.
- Unload the firearm and engage the safety.

2. Installation Steps:

- Remove the grip panels to access the internal components of the firearm.
- Carefully remove the old sear springs if applicable.
- Install the new 1911 AUTO "FACTORY PLUS" SEAR SPRINGS by following these steps:
 - Align the springs with the corresponding holes in the sear assembly.
 - Ensure that the springs are seated properly and securely.
- Reassemble the firearm by replacing the grip panels.

3. PostInstallation Check:

- After installation, check the functionality of the sear springs.
- Conduct a function test to ensure that the firearm operates correctly.
- If any issues arise, consult a qualified gunsmith.

Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- Do not throw away sear springs in regular household waste. Instead, take them to a designated recycling facility or hazardous waste disposal site.

Contact Information for Further Support

For any questions or concerns regarding the installation, usage, or safety of the 1911 AUTO "FACTORY PLUS" SEAR SPRINGS, please reach out to the manufacturer or a qualified gunsmith.

By following these guidelines and instructions, you can ensure the safe use of the 1911 AUTO "FACTORY PLUS" SEAR SPRINGS and maintain compliance with EU safety regulations. Thank you for your attention to safety.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at