


WALTHER P-38 SERVICE PAK - WALTHER SERVICE PAK

[Handgun Parts](#) > [Action Parts](#) > [Spring Kits](#)

All essential factory weight coil springs for a particular semi-auto pistol. No fitting required. Magazine spring not included. WALTHER P-38 - 9mm No firing pin spring. Kit #69491.



Attributes

- Name: [WALTHER SERVICE PAK](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969366510
- Mfr. No.: 69491
- Delivery weight: 0.014kg
- Shipping height: 5mm
- Shipping width: 79mm
- Shipping length: 196mm

Item details

Made in USA

Table of Contents

- Startpage
- [WALTHER P38 Service Pak Safety Instructions](#)
- About Us

WALTHER P38 Service Pak Safety Instructions

Introduction

Thank you for choosing the WALTHER P38 Service Pak. This product contains essential factory weight coil springs designed specifically for the WALTHER P38 semiautomatic pistol. To ensure your safety and the proper functioning of your firearm, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that all products are used in accordance with the manufacturer's instructions.
- Always treat firearms as if they are loaded, even if they are not.
- Store all firearm components and accessories in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when handling firearms.
- Ensure the firearm is pointed in a safe direction at all times.
- Do not attempt to modify any components or use parts not specified by the manufacturer.
- Be aware of your surroundings and ensure a safe shooting environment.
- Do not use the WALTHER P38 Service Pak if you are under the influence of drugs or alcohol.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded and the magazine is removed.
- Gather all necessary tools for installation.

2. Installation of Coil Springs

- Carefully remove the old springs from the WALTHER P38.
- Install the new coil springs from the WALTHER P38 Service Pak according to the following steps:
 - Identify the correct spring for each application as per the manufacturer's specifications.
 - Insert the new springs into their designated locations.
 - Ensure that the springs are seated properly and securely.

3. Final Checks

- After installation, perform a visual inspection to ensure all components are correctly installed.
- Conduct a function check of the firearm to ensure proper operation.
- If any issues are identified, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of any old or replaced springs in accordance with local regulations.
- Do not dispose of firearm components in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any safety inquiries or additional support regarding the WALTHER P38 Service Pak, please refer to the manufacturer's website or customer service resources.

By following these safety instructions, you can ensure the safe use of your WALTHER P38 Service Pak and maintain the performance of your firearm. Thank you for prioritizing safety.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at