

# RECOIL GUIDE ROD for GLOCK® - MODEL 19/23 GUIDE ROD

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

## Superior Support & Better Spring Alignment

Full-length, hardened steel guide rods help prevent spring bind and improves cycling. Lets you keep your factory, captive, recoil assembly intact and must use Wolff recoil springs. Machined from solid steel, polished, then hardened.



## Attributes

- Name: [MODEL 19/23 GUIDE ROD](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969502000
- Mfr. No.: 50200
- Make: Glock
- Model: 19,23
- Delivery weight: 0.027kg
- Shipping height: 13mm
- Shipping width: 76mm
- Shipping length: 193mm

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- RECOIL GUIDE ROD for GLOCK® MODEL 19/23 Safety Instructions
- About Us

# RECOIL GUIDE ROD for GLOCK® MODEL 19/23

## Safety Instructions

### Introduction

Thank you for purchasing the RECOIL GUIDE ROD for GLOCK® MODEL 19/23. This product is designed to enhance the performance of your firearm by preventing spring bind and improving cycling. To ensure your safety and the proper functioning of the product, please read and follow these safety instructions carefully.

### General Safety Guidelines

- Ensure safe use of the product by following all instructions.
- Be aware of potential hazards associated with improper installation or use.
- Use the product only with compatible Wolff recoil springs.
- Store the product in a safe place, away from children and vulnerable individuals.
- Regularly check for updates regarding product recalls and safety notices.

### Specific Safety Precautions for Use

- Always handle firearms with care and treat them as if they are loaded.
- Do not modify the recoil guide rod or any other firearm components.
- Ensure the firearm is unloaded before installing or removing the recoil guide rod.
- Wear appropriate eye protection when using firearms.
- Keep your hands and face clear of the recoil assembly during operation.
- If you notice any unusual behavior in your firearm, cease use immediately and consult a qualified gunsmith.

### Instructions for Installation and Usage

#### 1. Preparation:

- Ensure your firearm is completely unloaded.
- Gather necessary tools for installation.

#### 2. Installation Steps:

- Remove the slide from the frame of the GLOCK® pistol.
- Carefully remove the factory recoil assembly.
- Install the RECOIL GUIDE ROD by aligning it with the guide rod channel.
- Ensure that the rod is seated properly and securely in place.
- Reassemble the slide onto the frame, ensuring all components are correctly aligned.

#### 3. Usage:

- Use the firearm in accordance with manufacturer instructions.
- Regularly inspect the recoil guide rod for signs of wear or damage.
- Replace the recoil spring as needed to maintain optimal performance.

### Disposal Instructions

- Dispose of the RECOIL GUIDE ROD in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Contact local authorities or a waste disposal facility for guidance on proper disposal methods.

## **Contact Information for Further Support**

For further support, please consult the manufacturer's website or contact their customer service directly. Always refer to the product manual for specific inquiries related to your RECOIL GUIDE ROD.

By following these safety instructions, you can ensure the safe use and longevity of your RECOIL GUIDE ROD for GLOCK® MODEL 19/23. Thank you for prioritizing safety.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)