

TYPE B FACTORY REPLACEMENT SPRING FOR HARDBALL LOADS - 16 LB. GOVT. MODEL RECOIL SPRING, 10-PAK

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Fine Tune For Light, Standard Or Heavy Loads

Like all Wolff springs, these for the 1911 Auto in .45, .38 Super or 9mm are the finest, most reliable, longest lasting ones available. The springs of choice for most of the nation's top builders. Except where noted, all recoil springs are supplied with an extra power firing pin spring that keeps the firing pin stop in place and prevents firing pin float ; an addition recommended by pistolsmith Bill Wilson. TYPE B - Factory Replacement Spring For Hardball Loads exactly matches the specs of the original factory spring. Govt. Model does NOT come with extra power firing pin spring. Commander may also be used as an extra power spring for 9mm/.38 Super pistols and comes with an XP firing pin spring.



Attributes

- Name: [16 LB. GOVT. MODEL RECOIL SPRING, 10-PAK](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969950610
- Mfr. No.: 95060
- Make: 1911
- Model: Government
- Pounds: 16 lbs
- Delivery weight: 0.091kg
- Shipping height: 3mm
- Shipping width: 79mm
- Shipping length: 246mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TYPE B FACTORY REPLACEMENT SPRING FOR HARDBALL LOADS 16 LB. GOVT. MODEL RECOIL SPRING, 10PAK
- About Us

Safety Instruction Guide for TYPE B FACTORY REPLACEMENT SPRING FOR HARDBALL LOADS 16 LB. GOVT. MODEL RECOIL SPRING, 10PAK

Introduction

Thank you for choosing the TYPE B Factory Replacement Spring for Hardball Loads. This product is designed to enhance the performance of your firearm. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure safe use of the recoil spring by following all safety instructions.
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Store the recoil spring in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the recoil spring for wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Only use the TYPE B recoil spring with compatible firearms (1911 Auto in .45, .38 Super, or 9mm).
- Do not exceed the recommended load specifications when using this recoil spring.
- Ensure that the firearm is unloaded before installing or replacing the recoil spring.
- Wear safety glasses when handling or working with firearms.
- If you are inexperienced with firearm maintenance, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation (e.g., screwdriver, cleaning cloth).

2. Installation:

- Remove the slide from the firearm according to the manufacturer's instructions.
- Locate the existing recoil spring and remove it carefully.
- Inspect the guide rod and ensure it is clean and free of debris.
- Take the new TYPE B recoil spring and align it with the guide rod.
- Reinstall the slide onto the frame, ensuring that the recoil spring is seated properly.

3. Usage:

- After installation, perform a function check to ensure proper operation.
- Test the firearm in a safe and controlled environment.
- Monitor the performance of the recoil spring during use and replace it if signs of wear are evident.

Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations regarding metal waste.
- Do not dispose of the recoil spring in regular household waste.
- Consider recycling the spring if facilities are available in your area.

Contact Information for Further Support

For any safety inquiries or support regarding the TYPE B Factory Replacement Spring, please refer to the contact details provided by the manufacturer or retailer from whom you purchased the product.

Conclusion

Following these safety instructions will help ensure a safe and enjoyable experience with your TYPE B Factory Replacement Spring. Always prioritize safety and compliance with regulations when handling firearms. Thank you for your attention to these important guidelines.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at