

AR-15/M16 FORWARD ASSIST PIN 5 PACK - FORWARD ASSIST PIN

[Rifle Parts](#) > [Receiver Parts](#) > [Receiver Hardware](#) > [Receiver Pins](#)

Replacement Pins Keep Your AR Shooting

Genuine, Mil-spec quality small pins for the AR-15/M-16 that wear out, break, or just get lost. Great for creating your own emergency parts kits.



Attributes

- Name: [FORWARD ASSIST PIN](#)
- Manufacturer: [TTI INTL](#)
- Product no.: 989015016
- Mfr. No.: NONE
- Make: AR-15
- Delivery weight: 0.005kg
- Shipping width: 57mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AR15/M16 Forward Assist Pin 5 Pack
- About Us

Safety Instruction Guide for AR15/M16 Forward Assist Pin 5 Pack

Introduction

Thank you for choosing the AR15/M16 Forward Assist Pin 5 Pack. This product is designed to provide reliable replacements for the forward assist pins of your AR15 or M16. In order to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR), please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always handle the forward assist pins with care to avoid injury.
- Do not use damaged or wornout pins, as they may compromise the safety of your firearm.
- Ensure that the firearm is unloaded before attempting to replace the forward assist pins.
- Use appropriate tools when installing or removing the pins to avoid personal injury or damage to the firearm.
- Wear safety glasses to protect your eyes from small parts that may fly off during installation.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is completely unloaded.
- Gather the necessary tools: a punch tool and a hammer.

2. Removing the Old Pin

- Locate the forward assist pin on your AR15/M16.
- Using the punch tool, gently tap the old pin out of its position.
- Carefully remove the old pin and set it aside.

3. Installing the New Pin

- Take one of the new forward assist pins from the pack.
- Align the new pin with the hole where the old pin was removed.
- Using the punch tool, gently tap the new pin into place until it is secure.

4. Final Checks

- Ensure that the new pin is properly seated and does not move excessively.
- Conduct a visual inspection of the installation to confirm that everything is in order.
- Test the functionality of the forward assist mechanism before using the firearm.

Disposal Instructions

- Dispose of any old or damaged pins in accordance with local regulations.
- Do not dispose of the product in regular household waste. Instead, look for designated disposal sites for metal parts.

Contact Information for Further Support

For any inquiries regarding the product, please refer to the contact information provided by the manufacturer or authorized distributors. Ensure to have the product details ready when seeking assistance.

By following these instructions and safety guidelines, you can ensure that you use the AR15/M16 Forward Assist Pin safely and effectively. Thank you for your attention to these important safety measures.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at