

AR-15 PISTOL GRIP SCREW 5-PK BLUED STEEL

[Rifle Parts](#) > [Grip Parts](#) > [Pistol Grip Components](#)

Genuine, Mil-spec quality small parts for the AR-15/M-16 that wear out, break, or just get lost. Great for creating your own emergency parts kits.



Attributes

- Name: [AR-15 PISTOL GRIP SCREW 5-PK BLUED STEEL](#)
- Manufacturer: [TTI INTL](#)
- Product no.: 989015029
- Mfr. No.: NONE
- Color: Blued
- Make: AR-15
- Material: Steel
- Delivery weight: 0.036kg
- Shipping height: 1mm
- Shipping width: 57mm
- Shipping length: 89mm

Item details

Made in USA

Table of Contents

- Startpage
- AR15 PISTOL GRIP SCREW 5PK Safety Instruction Guide
- About Us

AR15 PISTOL GRIP SCREW 5PK Safety Instruction Guide

Introduction

Thank you for choosing the AR15 Pistol Grip Screw 5PK. This product is designed to replace worn, broken, or lost screws for your AR15/M16 pistol grip. It is important to follow safety guidelines to ensure proper use and installation. This guide provides essential safety information and instructions in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is suitable for your specific model of AR15/M16.
- Always handle tools and components with care to prevent injury.
- Keep all small parts away from children and pets to avoid choking hazards.
- Regularly inspect the screws for wear or damage before use.
- If you notice any defects or issues, discontinue use immediately and report it.

Specific Safety Precautions for Use

- Use only the specified tools for installation to avoid damaging the screws or the pistol grip.
- Do not overtighten screws, as this may strip the threads and compromise the grip.
- Ensure that the pistol grip is securely attached to the firearm before use.
- Follow the manufacturer's guidelines for your firearm to ensure compatibility and safety.
- Always wear safety goggles when working with tools to protect your eyes from debris.

Instructions for Installation and Usage

1. Preparation

- Gather the necessary tools: a screwdriver suitable for the screw heads.
- Ensure that the firearm is unloaded and pointed in a safe direction.

2. Removing Old Screws

- Carefully remove any existing screws from the pistol grip using the appropriate screwdriver.
- Set aside the old screws in a safe location.

3. Installing New Screws

- Align the new AR15 Pistol Grip Screws with the holes in the pistol grip.
- Insert each screw gently into the hole without forcing it.
- Use the screwdriver to tighten each screw until it is snug, but do not overtighten.

4. Final Check

- After installation, check that the pistol grip is securely attached.
- Perform a visual inspection to ensure that no screws are missing or loose.

Disposal Instructions

- Dispose of any old screws or packaging materials in accordance with local regulations.
- Do not dispose of screws in a manner that could pose a hazard to the environment or public safety.

Contact Information for Further Support

For any safety inquiries or concerns regarding this product, please refer to the EUbased contact point provided by the manufacturer. Always ensure that you have the product information available when seeking assistance.

Conclusion

By following these safety instructions, you can ensure the proper use and installation of the AR15 Pistol Grip Screw 5PK. Always prioritize safety and report any unsafe conditions or incidents to the appropriate authorities. Thank you for your attention to these important guidelines.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at