

Resetting Target - Handgun Resetting Target

[Shooting Accessories](#) > [Targets & Accessories](#) > [Steel Targets](#)

Caldwell® Resetting Targets are easily portable and create an interactive shooting experience that makes plinking and target practice fun. Made of heavy duty steel, these targets are built to last. All of our resetting targets come packaged in sturdy, partial clamshells. Holes are punched in the clamshells for hanging the product on the peg hooks. The rimfire and handgun models are reinforced with zip ties to ensure the heavy product is secured inside.

NO IMAGE
AVAILABLE

Attributes

- Name: [Handgun Resetting Target](#)
- Manufacturer: [Caldwell](#)
- Product no.: EU1000209
- Mfr. No.: 1071002
- Colour: Black
- Style: Handgun
- Delivery weight: 6.62kg
- Shipping height: 302mm
- Shipping width: 51mm
- Shipping length: 749mm
- UPC: 661120036548

Table of Contents

- Startpage
- Caldwell Resetting Target Safety Instruction Guide
- About Us

Caldwell Resetting Target Safety Instruction Guide

Introduction

Thank you for choosing the Caldwell Resetting Target. This guide provides essential safety instructions and guidelines to ensure safe and effective use of your resetting target. Please read this guide carefully before use.

General Safety Guidelines

- Ensure the Caldwell Resetting Target is used in a safe environment, away from people, pets, and property.
- Always wear appropriate safety gear, including eye and ear protection, when using firearms.
- Keep the resetting target in good condition. Inspect it for any damage before each use.
- Follow all local laws and regulations regarding target shooting and firearm use.
- Ensure that all users of the resetting target are of legal age and have received proper training in firearm safety.

Specific Safety Precautions for Use

- Do not use the resetting target in inclement weather (e.g., rain, snow, or high winds) to avoid accidents.
- Always ensure the target is securely set up and stable before shooting.
- Do not attempt to retrieve or adjust the target while shooting is in progress.
- Avoid shooting the target with firearms that exceed the recommended caliber.
- Be aware of your surroundings and ensure a clear line of sight before shooting.

Instructions for Installation and Usage

• Installation:

- Choose a flat, stable surface to set up the resetting target.
- Hang the target securely using the prepunched holes in the clamshell packaging.
- Ensure that the target is at a safe distance from the shooting area, typically at least 10 yards for handguns.

• Usage:

- Load your firearm and ensure it is pointed in a safe direction.
- Aim carefully at the target and take your shot.
- After hitting the target, observe it resetting. Do not shoot again until you confirm it is safe to do so.
- If the target fails to reset, do not approach it until you have ensured the area is safe.

Disposal Instructions

- Dispose of the Caldwell Resetting Target in accordance with local regulations.
- If the target is damaged beyond repair, contact your local waste management facility for proper disposal methods.
- Do not burn the target or its packaging materials.

Contact Information for Further Support

For any questions or concerns regarding the Caldwell Resetting Target, please refer to the manufacturer's

website or customer service for assistance.

Thank you for following these safety instructions. Enjoy your shooting experience responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk