

Omnipotence Li-Ion Battery Pack

[Shooting Accessories](#) > [Range Gear](#) > [Cameras](#)

The NEW Omnipotence Li-ion Battery pack is a rechargeable lithium ion battery used to replace the 6AA battery tray included with BOG Game cameras, and is designed to extend the life of BOG game cameras for more than a full year's use.

NO IMAGE
AVAILABLE

Attributes

- Name: [BOG Omnipotence Li-Ion Battery Pack](#)
- Manufacturer: [BOG](#)
- Product no.: EU1001660
- Mfr. No.: 1116329
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 3mm
- Shipping length: 32mm
- UPC: 661120080480

Table of Contents

- [Startpage](#)
- [BOG Omnipotence Lilon Battery Pack Safety Instructions](#)
- [About Us](#)

BOG Omnipotence Lilon Battery Pack Safety Instructions

Introduction

Thank you for choosing the BOG Omnipotence Lilon Battery Pack. This rechargeable lithiumion battery is designed to replace the 6AA battery tray included with BOG Game cameras, extending their life for over a year. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as specified in this manual.
- Keep the battery pack out of reach of children and vulnerable individuals.
- Do not expose the battery pack to extreme temperatures, moisture, or direct sunlight.
- Regularly inspect the battery pack for any signs of damage, such as swelling, leakage, or corrosion.
- In case of any abnormalities, discontinue use immediately and follow the disposal instructions below.
- Always follow local regulations regarding the disposal of batteries.

Specific Safety Precautions for Use

- Do not attempt to open or disassemble the battery pack.
- Avoid shortcircuiting the battery terminals.
- Do not mix the battery pack with other types of batteries or use it with incompatible devices.
- Charge the battery pack only with the recommended charger to prevent overheating or fire hazards.
- Never leave the battery pack unattended while charging.
- If the battery pack is dropped or damaged, do not use it and dispose of it properly.

Instructions for Installation and Usage

1. Installation:

- Ensure the BOG Game camera is turned off before installation.
- Remove the existing 6AA battery tray from the camera.
- Insert the BOG Omnipotence Lilon Battery Pack into the battery compartment, ensuring correct polarity.
- Secure the battery compartment cover.

2. Usage:

- Turn on the BOG Game camera to confirm that it is powered by the battery pack.
- Monitor the battery level indicator on the camera, if available, to ensure proper functioning.
- Recharge the battery pack when the camera indicates low battery status.
- To recharge, remove the battery pack from the camera and connect it to the appropriate charger.

Disposal Instructions

- Dispose of the BOG Omnipotence Lilon Battery Pack in accordance with local regulations for lithiumion batteries.
- Do not dispose of the battery pack in regular household waste.
- Take the battery pack to a designated recycling facility or collection point for hazardous waste.

Contact Information for Further Support

For safety inquiries or further assistance, please reach out to the relevant contact point in your EU country. Ensure you have the product details ready for efficient support.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the BOG Omnipotence Lilon Battery Pack with your BOG Game cameras.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk