

Triple Play Tripod Ground Blind Chair

Emergency & Survival Gear

The BOG Triple Play™ Chair was designed to be the ultimate carry-in hunting chair. Constructed with a lightweight, yet durable aluminum frame, this chair weighs in at just 4.5 lbs, while supporting up to 300 lbs. The ultra-comfortable textilene® fabric, combined with a generously sized seat that eliminates pinch points, allows hunters to comfortably sit all day, waiting for that buck of a lifetime to walk by.

NO IMAGE
AVAILABLE

Attributes

- Name: [BOG Triple Play Tripod Ground Blind Chair](#)
- Manufacturer: [BOG](#)
- Product no.: EU1001696
- Mfr. No.: 1117130
- Colour: Black
- Delivery weight: 2.72kg
- Shipping height: 127mm
- Shipping width: 127mm
- Shipping length: 767mm
- UPC: 661120103424

Table of Contents

- Startpage
- BOG Triple Play Tripod Ground Blind Chair Safety Instructions
- About Us

BOG Triple Play Tripod Ground Blind Chair Safety Instructions

Introduction

Thank you for choosing the BOG Triple Play™ Tripod Ground Blind Chair. This chair is designed to provide comfort and support for hunters. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always inspect the chair before each use for any signs of damage or wear.
- Ensure that the chair is set up on a stable and level surface to prevent tipping.
- Do not exceed the maximum weight limit of 300 lbs.
- Keep the chair away from fire, heat sources, and sharp objects.
- Use the chair only for its intended purpose; do not use it for climbing or as a step stool.
- Store the chair in a dry place when not in use to prevent damage from moisture.
- If you notice any defects or issues with the chair, discontinue use immediately and report the problem.

Specific Safety Precautions for Use

- Ensure that the chair is fully opened and locked into place before sitting down.
- When sitting down or getting up, do so slowly to maintain balance.
- Avoid sudden movements while seated to prevent tipping.
- Do not allow more than one person to use the chair at a time.
- Keep children and pets away from the chair while in use to avoid accidents.
- Regularly check the chair's joints and connections to ensure they are secure.

Instructions for Installation and Usage

1. Unpacking the Chair

- Carefully remove the chair from its packaging.
- Ensure all parts are included and in good condition.

2. Setting Up the Chair

- Locate the chair's folding mechanism.
- Unfold the chair by pulling up on the seat until it clicks into place.
- Ensure that all legs are fully extended and locked.

3. Using the Chair

- Approach the chair from the front.
- Stand in front of the chair and gently lower yourself onto the seat.
- Adjust your position for comfort, ensuring that your weight is evenly distributed.

4. Folding the Chair for Storage

- Stand up from the chair and ensure it is empty.
- Locate the folding mechanism and carefully pull it to collapse the chair.
- Store the chair in a safe, dry location.

Disposal Instructions

- When the chair reaches the end of its life or is no longer usable, dispose of it responsibly.
- Check local regulations for disposal of aluminum and fabric materials.
- If possible, recycle the aluminum frame and dispose of fabric in accordance with local waste management guidelines.

Contact Information for Further Support

For questions or concerns regarding the BOG Triple Play™ Tripod Ground Blind Chair, please refer to the manufacturer's website or customer support resources.

Thank you for following these safety instructions to ensure a safe and enjoyable hunting experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk