

ACC Chassis System Kit Savage - MDT ACC Chassis System Savage 10, 11, 12, 16 RH FDE

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The rifle (system) and scope shown in the picture are not for sale and are not included. Only the chassis is included in the delivery.

The ACC (Adjustable Core Competition) Chassis was created with an integrated weight management system, allowing shooters to fine tune the weight and balance point of the rifle. The adjustability comes from a series of weights that can be added to either the buttstock, interior forend or exterior forend. It's original weight of 2,7 kg transforms into a maximum of 5,6 kg (chassis only - add on your action, barrel, scope and accessories and most shooters are pushing 12-14 kg in the ACC).

NO IMAGE
AVAILABLE

- 17" of available ARCA/RRS dovetail, with retention screw so that accessories don't fall off mid-stage.
- Comes with the MDT Elite Grip.
- Uses MDT's proprietary XTN buttstock interface (adjustable stock included).
- Compatible with AICS style magazines (sold separately).
- Interior forend weights, exterior M-Lok weights and buttstock weights available.

Attributes

- Name: [MDT ACC Chassis System Savage 10, 11, 12, 16 RH FDE](#)
- Manufacturer: [MDT](#)
- Product no.: EU2004090
- Mfr. No.: 104263-FDE
- Action Type: Short
- Colour: FDE
- Hand (RH LH): Right
- Material: Aluminum
- Model: 10,11,12,16
- Style: Chassis
- Weapon type: Savage
- Delivery weight: 3.6kg
- Shipping height: 200mm
- Shipping width: 100mm
- Shipping length: 950mm
- UPC: 682131925386

Table of Contents

- [Startpage](#)
- [MDT ACC Chassis System Safety Instruction Guide](#)
- [About Us](#)

MDT ACC Chassis System Safety Instruction Guide

Introduction

Thank you for choosing the MDT ACC Chassis System Kit for your Savage rifle. This guide provides essential safety instructions to ensure the safe and effective use of the chassis system. Please read this document carefully before installation and use.

General Safety Guidelines

- Always handle firearms with care and follow the manufacturer's safety instructions.
- Ensure that the chassis system is compatible with your specific rifle model (Savage 10, 11, 12, 16 RH).
- Be aware of the weight of the chassis system when fully assembled. The chassis can weigh between 2.7 kg and 5.6 kg, and the total weight may reach 1214 kg when including additional components.
- Regularly inspect the chassis system for any signs of wear or damage. Do not use the product if it is damaged.
- Keep the chassis system out of reach of children and unauthorized users.
- Use the chassis system in a safe and controlled environment, away from distractions and hazards.

Specific Safety Precautions for Use

- Always ensure that the rifle is unloaded before installing or adjusting the chassis system.
- Use only the specified MDT Elite Grip and MDT's proprietary XTN buttstock interface to ensure proper fit and safety.
- When adding weights to the chassis, ensure they are securely attached to prevent them from falling off during use.
- Be cautious of the ARCA/RRS dovetail when attaching accessories; ensure that the retention screw is tightened properly.
- If using the chassis in a competitive setting, familiarize yourself with the rules and regulations regarding weight and balance adjustments.

Instructions for Installation and Usage

1. Installation of the Chassis System:

- Ensure that the rifle is unloaded and point the muzzle in a safe direction.
- Remove the existing stock from the rifle according to the manufacturer's instructions.
- Align the rifle action with the MDT ACC Chassis and carefully secure it using the provided hardware.
- Ensure that all screws and fasteners are tightened to the manufacturer's specifications.

2. Adding Weights:

- Identify the desired location for weight adjustment (buttstock, interior forend, or exterior forend).
- Select the appropriate weights (interior forend weights, exterior MLoc weights, or buttstock weights).
- Attach the weights securely, ensuring they do not interfere with the operation of the rifle.

3. Using the Chassis System:

- Adjust the MDT Elite Grip and the XTN buttstock interface to fit your comfort and shooting style.
- Practice proper shooting stance and grip to ensure stability and accuracy.
- Regularly check the tightness of all components during use.

Disposal Instructions

- Dispose of the chassis system and any components in accordance with local waste disposal regulations.
- Do not dispose of the chassis system in household waste. Instead, consider recycling options for metal components.
- Ensure that any hazardous materials (e.g., batteries, if applicable) are disposed of according to local regulations.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the manufacturer's website or contact their customer support for assistance.

Thank you for your attention to these safety instructions. Your safety and the safety of others is our top priority. Enjoy using your MDT ACC Chassis System responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk