

# SEATERHEADS - TRIEBEL Seaterhead - Caliber 6,5/.264 - Type: R45

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

**You will find further informations in the manual.**

[The manual can be found here](#)

NO IMAGE  
AVAILABLE

## Attributes

- Name: [TRIEBEL Seaterhead - Caliber 6,5/.264 - Type: R45](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008284
- Mfr. No.: 3000089
- Diameter (in): 0.264
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

# Table of Contents

- Startpage
- TRIEBEL Seaterhead Safety Instruction Guide
- About Us

# TRIEBEL Seaterhead Safety Instruction Guide

## Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 6,5/.264 Type: R45. This product is designed to enhance your reloading experience with safety and efficiency. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Always handle the Seaterhead with care and ensure that it is used in accordance with the manufacturer's instructions.
- Inspect the product before each use for any signs of damage or wear. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Ensure that your workspace is clean, dry, and free from distractions while using the Seaterhead.
- Use the product only for its intended purpose as specified in the manual.

## Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seaterhead.
- Ensure that the Seaterhead is securely attached to the reloading press before use.
- Avoid placing your hands near moving parts while the Seaterhead is in operation.
- Do not exceed the recommended specifications for the Seaterhead, including caliber and load limits.
- Be aware of the risks associated with reloading, including the potential for explosive materials.
- Always follow the manufacturer's guidelines for the handling and storage of reloading components.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the reloading press is turned off and disconnected from any power source.
- Remove any existing Seaterhead from the press.
- Align the TRIEBEL Seaterhead with the press and secure it in place according to the manufacturer's instructions.
- Ensure that the Seaterhead is properly calibrated for the caliber 6,5/.264.

### 2. Usage:

- Prepare your reloading components according to safe reloading practices.
- Set the desired seating depth as per your reloading specifications.
- Insert the cartridge case into the Seaterhead and ensure it is properly positioned.
- Apply consistent pressure on the press handle to seat the bullet.
- Inspect each completed round for proper seating and visual defects before storage or use.

## Disposal Instructions

- Dispose of any unused or expired reloading components in accordance with local regulations.
- Do not dispose of the Seaterhead in regular household waste. Follow local guidelines for the disposal of metal products.
- Ensure that all materials are disposed of in a manner that does not pose a risk to the environment.

## Contact Information for Further Support

For any inquiries regarding safety, usage, or installation, please contact our customer support team or refer to the product manual for further assistance.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)