

SEATERHEADS - TRIEBEL Seaterhead - Caliber 6,5/.264 - Type: R80

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 6,5/.264 - Type: R80](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008292
- Mfr. No.: 3000091
- Diameter (in): 0.264
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterhead Safety Instructions
- About Us

TRIEBEL Seaterhead Safety Instructions

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 6,5/.264 Type: R80. This product is designed to enhance your reloading experience with precision and safety in mind. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always handle the Seaterhead with care to avoid injury.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seaterhead for any signs of wear or damage before use.
- If you notice any defects, do not use the product and contact customer support.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Improper use may lead to personal injury or damage to property.
 - Ensure that all components are compatible with the Seaterhead.
- **Avoiding Hazards:**
 - Use the Seaterhead in a wellventilated area to avoid inhaling any fumes.
 - Wear appropriate safety gear, such as goggles and gloves, when using the Seaterhead.
 - Do not exceed the recommended specifications for the Seaterhead.
 - Follow all manufacturer guidelines when using the Seaterhead with crimp and benchrest seaters.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure the work area is clean and free from obstructions.
 2. Confirm that the Seaterhead is compatible with your reloading equipment.
 3. Securely attach the Seaterhead to the reloading press according to the manufacturer's instructions.
 4. Doublecheck all connections to ensure they are tight and secure.
- **Usage:**
 1. Before starting, read the manual for specific instructions related to your equipment.
 2. Set up your reloading press and ensure it is stable.
 3. Follow the recommended procedures for seating the bullet.
 4. Regularly check for any unusual noises or resistance during operation.
 5. After use, clean the Seaterhead to maintain its performance.

Disposal Instructions

- Dispose of the Seaterhead in accordance with local regulations.
- Do not discard in general waste; check for recycling options.
- Ensure that any unused or damaged components are disposed of safely to prevent accidents.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the EUbased contact provided with your product.

Thank you for prioritizing safety while using the TRIEBEL Seaterhead. Your attention to these guidelines helps ensure a safe and enjoyable reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk