

# SEATERHEADS - TRIEBEL Seaterhead - Caliber 9,5/.375 - Type: R41

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

**You will find further informations in the manual.**

[The manual can be found here](#)

NO IMAGE  
AVAILABLE

## Attributes

- Name: [TRIEBEL Seaterhead - Caliber 9,5/.375 - Type: R41](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008398
- Mfr. No.: 3000197
- Diameter (in): 0.375
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

# Table of Contents

- Startpage
- Safety Instruction Guide for TRIEBEL Seaterhead Caliber 9,5/.375 Type: R41
- About Us

# Safety Instruction Guide for TRIEBEL Seaterhead

## Caliber 9,5/.375 Type: R41

### Introduction

Thank you for choosing the TRIEBEL Seaterhead. This product is designed to enhance your reloading experience while ensuring safety and compliance with the EU General Product Safety Regulation (GPSR). Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

### General Safety Guidelines

- Ensure that you have read and understood all safety instructions before using the TRIEBEL Seaterhead.
- Always use the product in accordance with the manufacturer's guidelines.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about recall updates via the EU Safety Gate platform.

### Specific Safety Precautions for Use

- Use only with compatible seater and crimp tools from Triebel.
- Do not exceed the recommended specifications for the product.
- Always wear appropriate safety gear, such as eye protection, when using the product.
- Do not modify the product in any way.
- Ensure a stable and secure work environment to prevent accidents during use.
- Be aware of your surroundings and avoid distractions while using the product.

### Instructions for Installation and Usage

#### 1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Carefully remove the TRIEBEL Seaterhead from its packaging.
- Attach the Seaterhead to the reloading press according to the manufacturer's instructions.
- Make sure the Seaterhead is securely fastened and properly aligned.

#### 2. Usage:

- Before starting, doublecheck that all components are correctly installed.
- Set the desired seating depth according to your specifications.
- Load the case into the press and engage the Seaterhead.
- Apply steady pressure while operating the press to ensure proper seating.
- After use, clean the Seaterhead to maintain its performance and longevity.

### Disposal Instructions

- Dispose of the TRIEBEL Seaterhead and any packaging materials in accordance with local regulations.
- Do not dispose of the product in household waste. Check with local authorities for recycling options.
- Ensure that any hazardous materials are handled and disposed of safely.

## **Contact Information for Further Support**

For any questions or concerns regarding the TRIEBEL Seaterhead, please refer to the manufacturer's website or contact your local distributor for assistance. Always ensure that you have the latest information and support available.

By following these instructions, you can ensure safe and effective use of the TRIEBEL Seaterhead. Thank you for your attention to safety and compliance with EU regulations.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)