

Trigger-Cam 2.1

Aircraft grade aluminum and proprietary anti shock materials: Military grade design, engineered to withstand recoil force and unforgiving outdoor conditions

Dimensions L x W x H : 100mm x 50mm x 93.2mm

Weight: 453 grams

Rifle Scope Eyepiece compatibility: 32mm – 48mm

Smart Phone APP: TRIGGERCAM 2.1 APP available on Android, IOS & Huawei operating systems. Live streaming capability, video gallery, camera control, download and edit videos.

Memory: SD Card up to 128G, Class U3 or Above.

Wi-Fi: Integrated Wi-Fi with live streaming function and instant downloading of videos

Quick record: Switches on power and record function for instant recording

Optics: Multi coated optical lens for optimal performance.

Video stabilisation: Advanced video stabilisation technology assists in optimal quality videos minimising recoil effects. Function can be switched ON/OFF

Waterproof: IP64 rating

Battery: Integrated lithium ion battery with 2.5 hours recording time, and 10 hours standby time

High definition slow motion video replay: 4 x (1080P 100/120fps) / 8 x (720P 200/240fps)

True sound microphone: Able to record high quality sound 360 degree true sound, able to switch on and off

Resolution: 4K 30fps

1080P 120fps/60fps/30fps

720P 240fps/120fps

USB: C-type USB,

HDMI: Micro HDMI for TV output

Video output: PAL/NTSC

Recording Timing Alarm: Off/3min/5min/10min

Input Voltage: 5V

Other features: Auto low light function

What's in the box: 1 x TRIGGERCAM 2.1

NO IMAGE
AVAILABLE

1 x C-type USB Cable

32GB micro SD card

1 x Quick start guide



Attributes

- Name: Trigger-Cam 2.1
- Manufacturer: Eyecam Technologies Pty Ltd
- Product no.: EU2009008
- Mfr. No.:
- Color: Black
- Delivery weight: 1kg
- Shipping height: 70mm
- Shipping width: 220mm
- Shipping length: 260mm
- UPC: 737186687359

Table of Contents

- [Startpage](#)
- [English: TriggerCam 2.1 Safety Instruction Guide](#)
- [Polski: Instrukcja Bezpieczeństwa dla TriggerCam 2.1](#)

TriggerCam 2.1 Safety Instruction Guide

Introduction

Thank you for choosing the TriggerCam 2.1. This guide provides essential safety instructions to ensure safe and effective use of your product. Please read this guide carefully before using the TriggerCam 2.1 to understand its features, potential hazards, and how to operate it safely.

General Safety Guidelines

- **Product Safety:** The TriggerCam 2.1 is designed with safety in mind. Follow all instructions to minimize risks associated with its use.
- **Enhanced Recalls:** In case of any safety concerns, recall notices will be provided. Stay informed about product recalls through official channels.
- **Online Shopping Protections:** When purchasing online, ensure that the seller complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** This product is not intended for use by children. Ensure that it is kept out of reach of young children.
- **EU Contact Point:** For any safety inquiries, refer to the contact information provided with your product packaging.
- **Rapid Alerts:** Stay updated on product safety through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Avoid Exposure to Water:** Although the TriggerCam 2.1 has an IP64 waterproof rating, avoid submerging it in water.
- **Secure Installation:** Ensure that the camera is securely mounted to prevent it from falling or getting damaged during use.
- **Monitor Battery Levels:** Regularly check the battery level to avoid unexpected shutdowns during operation.
- **Avoid Extreme Temperatures:** Do not expose the camera to extreme heat or cold, as this may affect its performance.
- **Handle with Care:** The camera is made from aircraftgrade aluminum and antishock materials, but it is still important to handle it carefully to avoid damage.
- **Use the Correct Accessories:** Only use the recommended SD cards (Class U3 or above) and USB cables to ensure optimal performance.
- **Keep Away from Children:** This product is not a toy. Ensure it is stored in a safe location away from children.

Instructions for Installation and Usage

- **Installation:**

1. Choose a stable surface or mount to secure the TriggerCam 2.1.
2. Ensure the camera is positioned to capture the desired field of view.
3. Use the provided Ctype USB cable to connect to power if necessary.

- **Usage:**

1. **Power On:** Press the power button to turn on the device.
2. **Recording:** Use the quick record function to start recording instantly.
3. **Live Streaming:** Connect to the TRIGGERCAM 2.1 app on your smartphone for live streaming and camera control.
4. **Adjust Settings:** Access the app to configure video resolution, frame rates, and other settings.

5. **Stop Recording:** Press the power button again to stop recording, or use the app to control the recording.

- **After Use:**

1. Power off the device to conserve battery.
2. Store the camera in a safe, dry place.

Disposal Instructions

- **Electronic Waste:** The TriggerCam 2.1 contains electronic components. Dispose of it according to local electronic waste disposal regulations.
- **Battery Disposal:** The integrated lithiumion battery must be disposed of properly. Do not throw it in regular waste. Follow local guidelines for battery disposal.

Contact Information for Further Support

For further assistance, please refer to the support contact information provided with your product packaging or visit the manufacturer's website.

By following these guidelines, you can ensure the safe and effective use of your TriggerCam 2.1. Thank you for your attention to safety!

Instrukcja Bezpieczeństwa dla TriggerCam 2.1

Wprowadzenie

Dziękujemy za zakup TriggerCam 2.1. Naszym celem jest zapewnienie bezpiecznego i satysfakcjonującego użytkowania produktu. Prosimy o uważne zapoznanie się z poniższymi instrukcjami bezpieczeństwa oraz zaleceniami, aby zminimalizować ryzyko i zapewnić prawidłowe działanie urządzenia.

Ogólne zasady bezpieczeństwa

- Używaj urządzenia zgodnie z przeznaczeniem, zgodnie z instrukcją obsługi.
- Przechowuj urządzenie w suchym i chłodnym miejscu, z dala od źródeł ciepła i wilgoci.
- Regularnie sprawdzaj urządzenie pod kątem uszkodzeń. W przypadku zauważenia jakichkolwiek uszkodzeń, nie używaj urządzenia i skontaktuj się z serwisem.
- Nie modyfikuj ani nie naprawiaj urządzenia samodzielnie. Wszelkie naprawy powinny być przeprowadzane przez autoryzowany serwis.
- Upewnij się, że wszystkie dzieci są pod stałym nadzorem podczas korzystania z urządzenia.

Specyficzne środki ostrożności podczas użytkowania

- Nie używaj urządzenia w warunkach, które mogą prowadzić do jego uszkodzenia, takich jak ekstremalne temperatury, nadmierna wilgotność czy wstrząsy.
- Unikaj kontaktu z wodą. Choć urządzenie ma klasę wodoodporności IP64, nie jest przeznaczone do zanurzenia w wodzie.
- Upewnij się, że bateria jest naładowana przed rozpoczęciem nagrywania, aby uniknąć przerwania pracy w trakcie użycia.
- Nie używaj urządzenia w pobliżu intensywnych pól elektromagnetycznych, które mogą zakłócać jego działanie.
- Zawsze używaj oryginalnych akcesoriów, takich jak kabel USB typu C, aby zapewnić optymalne działanie.

Instrukcje dotyczące instalacji i użytkowania

1. Rozpakowanie produktu:

- Otwórz opakowanie i upewnij się, że wszystkie elementy są obecne:
 - 1 x TRIGGERCAM 2.1
 - 1 x Kabel USB typu C
 - 1 x 32GB karta micro SD
 - 1 x Instrukcja szybkiego uruchomienia

2. Instalacja karty micro SD:

- Włóż kartę micro SD do odpowiedniego gniazda w urządzeniu, upewniając się, że jest prawidłowo umiejscowiona.

3. Ładowanie urządzenia:

- Podłącz kabel USB typu C do urządzenia oraz do źródła zasilania, aby naładować wbudowaną baterię litowojonową.

4. Włączanie urządzenia:

- Włącz TriggerCam 2.1, przytrzymując przycisk zasilania przez kilka sekund.

5. Używanie aplikacji:

- Zainstaluj aplikację TRIGGERCAM 2.1 na swoim smartfonie (dostępna na systemy Android, iOS i Huawei).
- Połącz urządzenie z aplikacją, aby uzyskać dostęp do funkcji takich jak transmisja na żywo, galeria wideo i kontrola kamery.

6. Nagrywanie:

- Upewnij się, że urządzenie jest odpowiednio ustawione i skierowane na obiekt, który chcesz nagrać.
- Włącz funkcję nagrywania, aby rozpocząć rejestrację.

7. Odtwarzanie i edytowanie:

- Po zakończeniu nagrania użyj aplikacji, aby odtworzyć lub edytować zarejestrowane filmy.

Instrukcje dotyczące utylizacji

- Utylizuj urządzenie zgodnie z lokalnymi przepisami dotyczącymi odpadów elektronicznych.
- Nie wyrzucaj urządzenia do zwykłych odpadów. Skontaktuj się z lokalnym punktem zbiórki elektrośmieci, aby uzyskać informacje na temat właściwej utylizacji.

Informacje kontaktowe dla dalszego wsparcia

W przypadku pytań lub wątpliwości dotyczących bezpieczeństwa produktu, skontaktuj się z odpowiednim punktem kontaktowym w Unii Europejskiej.

Zgłaszanie produktów niebezpiecznych

- W przypadku zauważenia niebezpiecznego działania produktu lub wypadku, zgłoś to odpowiednim władzom.
- Regularnie sprawdzaj aktualizacje dotyczące wycofań produktów na platformie Safety Gate Unii Europejskiej.

Dziękujemy za przestrzeganie powyższych wskazówek i życzymy udanego korzystania z TriggerCam 2.1!