

SEATERHEADS - TRIEBEL Seaterhead - Caliber 10,36/.408 - Type: R165

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 10,36/.408 - Type: R165](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2009052
- Mfr. No.: 3000215
- Diameter (in): 0.408
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterhead Safety Instruction Guide
- About Us

TRIEBEL Seaterhead Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 10,36/.408 Type: R165. This product is designed to assist in the precise seating of bullets in reloading processes. To ensure your safety and the proper use of this accessory, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure that the product is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities immediately.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the TRIEBEL Seaterhead only with compatible Seater and BenchRestSeaters from Triebel.
- Ensure that the work area is clean, dry, and free from distractions while using the product.
- Wear appropriate safety gear, including eye protection, to prevent injury during use.
- Do not exceed the recommended specifications for the product, including the caliber and diameter.
- Avoid using the product if it has been modified or damaged in any way.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is securely mounted on a stable surface.
- Attach the TRIEBEL Seaterhead to the reloading press according to the manufacturer's instructions.
- Confirm that the Seaterhead is properly aligned and tightened before use.

2. Usage:

- Set the desired seating depth according to your reloading specifications.
- Place the cartridge case into the reloading press and ensure it is held securely.
- Carefully insert the bullet into the case mouth.
- Activate the press to seat the bullet to the specified depth.
- Inspect the completed cartridge for proper seating and alignment.

Disposal Instructions

- Dispose of any product packaging and materials in accordance with local regulations.
- If the product is no longer in use, ensure it is disposed of safely to prevent accidents.
- Consider recycling components where applicable to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact information provided in the product manual.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy using your TRIEBEL Seaterhead responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk