

SEATERHEADS - TRIEBEL Seaterhead - Caliber 12,95/.500 - Type: R148

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 12,95/.500 - Type: R148](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2009061
- Mfr. No.: 3000243
- Diameter (in): .500
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterhead Safety Instruction Guide
- About Us

TRIEBEL Seaterhead Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 12,95/.500 Type: R148. This product is designed to enhance your reloading experience with safety and efficiency. Please read this safety instruction guide carefully to ensure safe handling, installation, and usage.

General Safety Guidelines

- Always handle firearms and reloading equipment with care and respect.
- Ensure that the product is used only for its intended purpose as described in this manual.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of damage or wear before use.
- Store the product in a dry, secure location when not in use.
- Familiarize yourself with local laws and regulations regarding reloading equipment and ammunition.

Specific Safety Precautions for Use

- Use protective eyewear when operating the seaterhead to prevent eye injuries.
- Avoid loose clothing and jewelry that may get caught in moving parts.
- Ensure that your work area is welllit and free from distractions.
- Do not exceed the recommended specifications for the seaterhead.
- Always follow the manufacturer's instructions for the specific reloading process.
- If you experience any unusual noise or resistance during operation, stop using the product immediately and inspect it for issues.

Instructions for Installation and Usage

1. Installation

- Ensure that the reloading press is securely mounted to a stable work surface.
- Attach the TRIEBEL Seaterhead to the reloading press according to the manufacturer's instructions.
- Ensure that all connections are tight and secure before use.

2. Usage

- Before starting, read the reloading manual for specific instructions related to your caliber and load.
- Place the casing securely in the seaterhead.
- Adjust the seating depth according to your specifications.
- Operate the reloading press smoothly and steadily to ensure consistent results.
- After completing the reloading process, check each round for proper seating and crimping.

Disposal Instructions

- Dispose of any unused or damaged products in accordance with local regulations.
- Do not dispose of the product in household waste. Contact local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the TRIEBEL Seaterhead, please refer to the contact information provided in your product packaging or visit the manufacturer's website.

Conclusion

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience with your TRIEBEL Seaterhead. Always prioritize safety and stay informed about best practices in reloading. Thank you for your attention to these safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk