

SEATERHEADS - TRIEBEL Seaterhead - Caliber 12,95/.500 - Type: R75

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 12,95/.500 - Type: R75](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2009064
- Mfr. No.: 3000242
- Diameter (in): .500
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- [Startpage](#)
- [TRIEBEL Seaterhead Safety Instructions](#)
- [About Us](#)

TRIEBEL Seaterhead Safety Instructions

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 12,95/.500 Type: R75. This product is designed to enhance your reloading experience by providing a reliable accessory for seater and crimping applications. To ensure your safety and the effective use of this product, please read the following safety instructions carefully.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as outlined in this manual.
- Always handle the product with care to prevent accidents or injuries.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear before use.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Use only with compatible seater and crimping equipment from Triebel.
- Do not exceed the manufacturer's recommended usage limits.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the product.
- Ensure that the workspace is clean and free from any obstructions before starting.
- Avoid distractions while using the product to maintain focus and control.

Instructions for Installation and Usage

1. Installation

- Ensure that the reloading press is turned off and unplugged.
- Remove any existing accessories from the press.
- Carefully attach the TRIEBEL Seaterhead to the reloading press, ensuring it is securely fastened.
- Doublecheck that all connections are tight and stable before proceeding.

2. Usage

- Adjust the seaterhead to the desired depth according to your reloading specifications.
- Insert the appropriate caliber cases into the reloading press.
- Follow the manufacturer's guidelines for the correct amount of powder and bullet seating.
- Operate the press smoothly and steadily to avoid any sudden movements that could lead to accidents.
- After use, clean the seaterhead and surrounding area to maintain optimal performance.

Disposal Instructions

- Dispose of any packaging materials responsibly and in accordance with local waste disposal regulations.
- If the product is no longer usable, check with local recycling programs for proper disposal methods.
- Do not throw the product in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any inquiries or concerns regarding the TRIEBEL Seaterhead, please refer to the manufacturer's contact information provided in the product manual or packaging.

Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with the TRIEBEL Seaterhead. Always prioritize safety and adhere to the guidelines provided to minimize risks. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk