

Aiming Sight for LabRadar

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

Low profile Aiming Sight for the LabRadar

No more straws of pens attached to the LabRadar.

This 2 minute installation is a nice option to add to your LabRadar to make sure the LabRadar is always aimed at the target to get the best results possible.

Comes with the correct screw.

Just remove the original screw, install the Sight, use the replacement screw and you're good to go.

NO IMAGE
AVAILABLE

Attributes

- Name: [XTREME BALLISTICS Aiming Sight for LabRadar](#)
- Manufacturer: [XTREME BALLISTICS](#)
- Product no.: EU2009905
- Mfr. No.: XBSIGHT
- Colour: Black
- Sights: Iron
- Delivery weight: 0.03kg
- Shipping height: 41mm
- Shipping width: 35mm
- Shipping length: 42mm

Table of Contents

- Startpage
- XTREME BALLISTICS AIMING SIGHT FOR LABRADAR Safety Instruction Guide
- About Us

XTREME BALLISTICS AIMING SIGHT FOR LABRADAR Safety Instruction Guide

Introduction

Thank you for choosing the XTREME BALLISTICS Aiming Sight for LabRadar. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this guide carefully before installation and use.

General Safety Guidelines

- Always ensure that the Aiming Sight is installed properly to avoid accidents.
- Use the product only for its intended purpose as described in this guide.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage to the Aiming Sight before each use.
- Follow all local regulations regarding the use of aiming devices in your area.

Specific Safety Precautions for Use

- Avoid using the Aiming Sight in adverse weather conditions (e.g., heavy rain, strong winds) that could affect its performance.
- Do not attempt to modify or repair the Aiming Sight. If issues arise, consult a professional.
- Ensure that the target area is clear of people and obstacles before using the LabRadar with the Aiming Sight.
- Always wear appropriate safety gear (e.g., eye protection) when operating the LabRadar.

Instructions for Installation and Usage

1. Installation

- Gather the necessary tools, including a screwdriver.
- Remove the original screw from the LabRadar.
- Align the XTREME BALLISTICS Aiming Sight with the designated mounting area on the LabRadar.
- Insert the provided replacement screw and tighten it securely to ensure stability.

2. Usage

- Once installed, aim the LabRadar at your target using the Aiming Sight.
- Ensure that the LabRadar is level and properly positioned for accurate readings.
- Monitor the performance of the Aiming Sight during use to ensure it remains securely attached.

Disposal Instructions

- Dispose of the Aiming Sight in accordance with local regulations regarding electronic waste.
- Do not throw the product in regular household waste.
- Check for any recycling programs in your area that accept electronic devices.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the product packaging or your retailer for contact information.

Thank you for your attention to these safety instructions. Enjoy using your XTREME BALLISTICS Aiming Sight for

LabRadar safely and effectively!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk