

Spare Parts - Replacement recoil rod and spring for Volquartsen 22 LR rifles with threaded-in barrels.

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Replacement recoil rod and spring for Volquartsen 22 LR rifles with threaded-in barrels.

NO IMAGE
AVAILABLE

Attributes

- Name: [Replacement recoil rod and spring for Volquartsen 22 LR rifles with threaded-in barrels.](#)
- Manufacturer: [VOLQUARTSEN](#)
- Product no.: EU2016147
- Mfr. No.: VCS-SP-0403
- Colour: Silver
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- Startpage
- Volquartsen Spare Parts Safety Instructions
- About Us

Volquartsen Spare Parts Safety Instructions

Introduction

Thank you for choosing the Volquartsen Spare Parts Replacement recoil rod and spring for your Volquartsen 22 LR rifle with threadedin barrels. This guide provides essential safety instructions and guidelines to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure the product is compatible with your specific model of Volquartsen 22 LR rifle.
- Inspect the recoil rod and spring for any damage or wear before each use.
- Store the replacement parts in a dry and secure location away from children.
- Follow all local laws and regulations regarding firearm maintenance and modifications.
- Report any unsafe product incidents or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use only the recommended recoil rod and spring for your Volquartsen 22 LR rifle.
- Ensure the firearm is unloaded before installing or replacing the recoil rod and spring.
- Avoid using excessive force during installation to prevent damage to the rifle or parts.
- Keep hands and other body parts clear of moving parts during installation and usage.
- If you experience any malfunction or unusual behavior from the rifle, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure you have the necessary tools for installation (e.g., screwdrivers, pliers).
- Work in a welllit and clean area to avoid losing small parts.

2. Installation Steps:

- Step 1:** Ensure the firearm is unloaded. Remove the magazine and check the chamber.
- Step 2:** Disassemble the rifle according to the manufacturer's instructions.
- Step 3:** Remove the old recoil rod and spring from the rifle.
- Step 4:** Inspect the new recoil rod and spring for any defects.
- Step 5:** Install the new recoil rod and spring, ensuring they are seated properly.
- Step 6:** Reassemble the rifle following the manufacturer's instructions.
- Step 7:** Perform a function check to ensure everything operates correctly.

3. Usage:

- After installation, always check the functionality of the rifle before use.
- Regularly maintain and inspect the recoil rod and spring to ensure safe operation.

Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- Do not dispose of parts in regular household waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Volquartsen Spare Parts Replacement recoil rod and spring, please reach out to the appropriate EUbased contact point for safety inquiries.

By following these safety instructions, you can ensure the safe and effective use of your Volquartsen Spare Parts Replacement recoil rod and spring. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk