

# Accessories - Chronographs - MagnetoSpeed Softcase

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

The MagnetoSpeed Soft Case provides optimal protection for V3 and Sporter chronographs. Featuring custom foam inserts and convenient compartments, it securely stores all components in a compact, organized manner—perfect for transport in a backpack or range bag.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [MagnetoSpeed Softcase](#)
- Manufacturer: [MAGNETOSPEED](#)
- Product no.: EU2016402
- Mfr. No.: MS\_Softcase
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

# Table of Contents

- Startpage
- MagnetoSpeed Soft Case Safety Instructions
- About Us

# MagnetoSpeed Soft Case Safety Instructions

## Introduction

Thank you for choosing the MagnetoSpeed Soft Case. This product is designed to provide optimal protection for your V3 and Sporter chronographs. To ensure safe usage and longevity of your product, it is important to follow these safety instructions carefully.

## General Safety Guidelines

- Always inspect the soft case for any signs of damage before use.
- Ensure that the case is closed securely during transport to prevent the components from falling out.
- Keep the soft case away from extreme temperatures and moisture to avoid damage to the foam inserts and components.
- Do not overload the case beyond its capacity, as this may compromise its protective qualities.
- Store the soft case in a safe location, out of reach of children and pets.

## Specific Safety Precautions for Use

- When transporting the soft case, avoid placing heavy items on top of it to prevent crushing.
- Handle the soft case with care to avoid any accidental drops that could cause damage to the case or its contents.
- Do not use the soft case as a seat or step, as it is not designed to support weight.
- If the soft case becomes wet, allow it to dry completely before storing any components inside.

## Instructions for Installation and Usage

### 1. Unpacking the Soft Case

- Carefully remove the soft case from its packaging.
- Inspect the case and foam inserts for any damage.

### 2. Storing Components

- Place your V3 or Sporter chronograph into the designated compartment.
- Use the custom foam inserts to secure the chronograph and prevent movement.
- Store all additional components, such as cables and manuals, in the appropriate compartments.

### 3. Transporting the Soft Case

- Ensure that all zippers are fully closed before transporting.
- Carry the soft case using the handle or shoulder strap, if applicable.
- Avoid placing heavy objects on top of the soft case during transport.

### 4. Cleaning the Soft Case

- Use a damp cloth to wipe the exterior of the soft case.
- Allow the case to air dry completely before storing.

## Disposal Instructions

- Dispose of the soft case responsibly according to local regulations.
- If the soft case is damaged beyond use, consider recycling materials where possible.
- Do not dispose of the soft case in regular household waste if it contains electronic components.

## **Contact Information for Further Support**

For any questions or concerns regarding the MagnetoSpeed Soft Case, please refer to the contact information provided with your product or visit the manufacturer's website for support.

By following these safety instructions, you ensure not only the longevity of your MagnetoSpeed Soft Case but also your safety while using and transporting your chronographs. Thank you for your attention to these guidelines, and enjoy using your MagnetoSpeed Soft Case.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)