

Accessories - Chronographs - V3 Pic Rail Adapter

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

The V3 Rail Adapter allows you to use the MagnetoSpeed V3 on most pistols and short-barreled rifles equipped with a Picatinny rail. This adapter is specifically designed for the MagnetoSpeed V3 model, ensuring a secure fit and reliable performance.

Product Features:

- Compatible with most pistols and short-barreled rifles
- Quick and easy installation
- Rugged construction for long-term durability
- Optimized specifically for the MagnetoSpeed V3

NO IMAGE
AVAILABLE

Attributes

- Name: [V3 Pic Rail Adapter](#)
- Manufacturer: [MAGNETOSPEED](#)
- Product no.: EU2016405
- Mfr. No.: MS_RA
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- Startpage
- Safety Instruction Guide for Accessories Chronographs V3 Pic Rail Adapter
- About Us

Safety Instruction Guide for Accessories Chronographs V3 Pic Rail Adapter

Introduction

Thank you for choosing the Accessories Chronographs V3 Pic Rail Adapter. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read all sections carefully before using the adapter.

General Safety Guidelines

- Ensure that the adapter is compatible with your specific model of the MagnetoSpeed V3.
- Always inspect the adapter for any visible damage before use.
- Keep the adapter out of reach of children and vulnerable individuals.
- Do not use the adapter for any purpose other than its intended use.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the adapter only on firearms that are equipped with a Picatinny rail.
- Ensure that the firearm is unloaded before attaching or detaching the adapter.
- Do not attempt to modify the adapter in any way.
- Avoid using the adapter in extreme weather conditions, as this may affect its performance.
- Always follow the manufacturer's instructions for the use of the MagnetoSpeed V3.

Instructions for Installation and Usage

1. Installation

- Ensure that the firearm is unloaded.
- Align the adapter with the Picatinny rail on your firearm.
- Slide the adapter onto the rail until it is securely in place.
- Tighten any screws or fasteners as required to ensure a secure fit.

2. Usage

- Attach the MagnetoSpeed V3 to the adapter according to the manufacturer's instructions.
- Conduct a safety check to ensure that the adapter and MagnetoSpeed V3 are securely attached.
- Use the device in a safe environment, following all applicable safety protocols for firearms.

Disposal Instructions

- Dispose of the adapter according to local regulations for electronic waste.
- Do not dispose of the adapter in regular household waste.
- If the adapter is damaged or no longer functional, contact local waste management services for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please consult the manufacturer or your local distributor. It is essential to have access to support for any concerns that may arise during the use of the

Accessories Chronographs V3 Pic Rail Adapter.

Thank you for your attention to these safety guidelines. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk