

ACC Elite Chassis - MDT Chassis - ACC Elite - CZ 457 - RH - BLK

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The MDT ACC Elite is built for one purpose: winning matches. As the #1 chassis in the PRS and the choice of thousands of competitors worldwide, its reputation is backed by countless podium finishes. This platform provides the balance, stability, and control needed to run complex stages efficiently and deliver consistent hits under extreme pressure.

The ACC Elite is designed to stay rigid when it matters most. Featuring a strengthened forend, a solid center base, and a dedicated connector bar linking the grip to the buttstock, this chassis eliminates twisting and bending during recoil or when loading into a prop.

NO IMAGE
AVAILABLE

Precision Balance: With a full-length ARCA forend and a tunable weight system, you can use MDT Weights to create a perfectly balanced rifle. This setup ensures the rifle settles fast and stays locked on target naturally under recoil.

SRS-X Elite Buttstock: Achieve a perfect, natural position behind your rifle every time. The SRS-X Elite offers fast, toolless adjustments for:
Cheek rest height (back and front)
Length-of-pull (LOP)
Buttpad height

Elite Ergonomics: The Vertical Grip - Elite allows for back, front, and angle adjustments. When paired with the adjustable M-LOK thumb rest, you get a tailored hand placement that feels completely natural.

Barricade Mastery: The included underside grip tape helps the rifle "dig in" to barricades and bags, ensuring a stable hold from the first shot to the last.

Attributes

- Name: [MDT Chassis - ACC Elite - CZ 457 - RH - BLK](#)
- Manufacturer: [MDT](#)
- Product no.: EU2017111
- Mfr. No.: 107956-BLK
- Colour: Black
- Model: 457
- Style: Chassis
- Weapon type: CZ
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 990482730567

Table of Contents

- [Startpage](#)
- [ACC Elite Chassis MDT Chassis Safety Instructions](#)
- [About Us](#)

ACC Elite Chassis MDT Chassis Safety Instructions

Introduction

Thank you for choosing the ACC Elite Chassis MDT Chassis for your CZ 457 rifle. This product is designed to enhance your shooting experience while ensuring safety and performance. Please read this safety instruction guide thoroughly before using the product to ensure safe and effective operation.

General Safety Guidelines

- Always treat the chassis and rifle as if they are loaded.
- Ensure you are in a safe environment before handling the chassis and rifle.
- Follow all local laws and regulations regarding firearm use and storage.
- Keep the chassis and rifle out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage before use.
- Use only accessories and modifications that are compatible with the ACC Elite Chassis.

Specific Safety Precautions for Use

- Ensure the rifle is securely mounted in the chassis before use.
- Do not exceed the recommended weight limits when using MDT Weights.
- Adjust the SRSX Elite Buttstock and Vertical Grip Elite only when the rifle is unloaded and pointed in a safe direction.
- Be aware of your surroundings and ensure a clear line of sight before firing.
- Use the included underside grip tape to enhance stability but ensure it is properly applied to avoid slipping.

Instructions for Installation and Usage

Installation

1. Mounting the Rifle:

- Ensure the rifle is unloaded.
- Place the rifle into the chassis, aligning it with the designated mounting points.
- Secure the rifle using the provided screws and tools, ensuring a tight fit.

2. Adjusting the SRSX Elite Buttstock:

- Adjust the cheek rest height by loosening the adjustment knob and sliding the cheek rest to the desired height.
- Adjust the lengthofpull (LOP) by loosening the LOP adjustment knob and sliding the buttstock to the preferred length.
- Adjust the buttpad height by loosening the buttpad adjustment screws and moving the buttpad to the desired position.

3. Adjusting the Vertical Grip Elite:

- Loosen the grip adjustment screws to change the angle of the grip.
- Adjust the grip position to find a comfortable hand placement.

Usage

- Before firing, ensure the rifle is properly balanced using the MDT Weights if necessary.
- When using the chassis in a competitive setting, familiarize yourself with the specific rules and

regulations of the event.

- Maintain a firm grip and stance when firing to ensure stability and control.

Disposal Instructions

- Dispose of the chassis in accordance with local regulations regarding electronic waste and materials.
- Remove any accessories or components that can be recycled separately.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or support regarding the ACC Elite Chassis MDT Chassis, please refer to the contact information provided with your product.

Conclusion

By following these safety instructions, you will help ensure a safe and enjoyable shooting experience with your ACC Elite Chassis. Always prioritize safety and be aware of your surroundings when handling firearms. Thank you for your attention to these important safety guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk