

Chassis - ACC Elite System - Savage - SA - RH - MDT Chassis - ACC Elite System - CZ 457 - RH - BLK

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The MDT ACC Elite is built for one purpose: winning matches. As the #1 chassis in the PRS and the choice of thousands of competitors worldwide, its reputation is backed by countless podium finishes. This platform provides the balance, stability, and control needed to run complex stages efficiently and deliver consistent hits under extreme pressure.

The ACC Elite is designed to stay rigid when it matters most. Featuring a strengthened forend, a solid center base, and a dedicated connector bar linking the grip to the buttstock, this chassis eliminates twisting and bending during recoil or when loading into a prop.

NO IMAGE
AVAILABLE

Precision Balance: With a full-length ARCA forend and a tunable weight system, you can use MDT Weights to create a perfectly balanced rifle. This setup ensures the rifle settles fast and stays locked on target naturally under recoil.

SRS-X Elite Buttstock: Achieve a perfect, natural position behind your rifle every time. The SRS-X Elite offers fast, toolless adjustments for:
Cheek rest height (back and front)
Length-of-pull (LOP)
Buttpad height

Elite Ergonomics: The Vertical Grip - Elite allows for back, front, and angle adjustments. When paired with the adjustable M-LOK thumb rest, you get a tailored hand placement that feels completely natural.

Barricade Mastery: The included underside grip tape helps the rifle "dig in" to barricades and bags, ensuring a stable hold from the first shot to the last.

Attributes

- Name: [MDT Chassis - ACC Elite System - CZ 457 - RH - BLK](#)
- Manufacturer: [MDT](#)
- Product no.: EU2017114
- Mfr. No.: 107957-BLK
- Colour: Black
- Model: 457
- Style: Chassis
- Weapon type: CZ
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 990482730598

Table of Contents

- [Startpage](#)
- [MDT Chassis ACC Elite System Safety Instructions](#)
- [About Us](#)

MDT Chassis ACC Elite System Safety Instructions

Introduction

Thank you for choosing the MDT Chassis ACC Elite System. This product is designed to enhance your shooting experience while ensuring safety and reliability. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Ensure that the MDT Chassis is used according to the manufacturer's instructions to minimize risks.
- Always treat the chassis as if it is loaded, even when you believe it is not.
- Keep the chassis out of reach of children and unauthorized users.
- Inspect the chassis regularly for any signs of wear or damage before use.
- Use the chassis only with compatible firearms and accessories.
- Follow all local laws and regulations regarding firearm usage and storage.
- Be aware of your surroundings and ensure a safe shooting environment.

Specific Safety Precautions for Use

- **Handling:** Always handle the chassis with care. Do not place your finger on the trigger until you are ready to shoot.
- **Shooting Position:** Ensure a stable shooting position to prevent accidents. Use the adjustable features of the chassis to find a comfortable and secure position.
- **Recoil Management:** Be prepared for recoil. The MDT ACC Elite is designed to minimize twisting and bending, but always maintain a firm grip.
- **Environmental Awareness:** Be cautious of external factors such as wind, terrain, and obstacles that may affect your shooting stability.
- **Emergency Situations:** Familiarize yourself with emergency procedures in case of accidents or malfunctions.

Instructions for Installation and Usage

1. Installation:

- Ensure the rifle is unloaded before installation.
- Attach the MDT Chassis to the firearm according to the manufacturer's guidelines.
- Ensure all screws and connectors are tightened securely to avoid any movement during use.

2. Adjustments:

- Adjust the SRSX Elite Buttstock for optimal cheek rest height, length of pull (LOP), and butt pad height using the toolless adjustment features.
- Adjust the Vertical Grip Elite for back, front, and angle placements to achieve a natural hand position.

3. Weight System:

- Utilize the tunable weight system to balance the rifle according to your shooting style.
- Add or remove MDT Weights as needed to achieve the desired balance.

4. Shooting:

- Position yourself comfortably behind the rifle.

- Ensure the rifle is aimed at the target before engaging the trigger.
- Maintain focus and control throughout the shooting process.

Disposal Instructions

- Dispose of the MDT Chassis in accordance with local regulations concerning electronic and firearm components.
- Do not dispose of the chassis in regular household waste.
- Check with local authorities for proper disposal methods or recycling options.

Contact Information for Further Support

For any inquiries regarding safety, maintenance, or product support, please refer to the contact information provided with your product packaging or on the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure a safer and more enjoyable experience with your MDT Chassis ACC Elite System. Always prioritize safety and responsible usage when handling firearms and related equipment. Thank you for choosing MDT.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk