

Chassis - ACC Elite System - Savage - SA - RH - MDT Chassis - ACC Elite System - CZ 457 - RH - FDE

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The MDT ACC Elite is built for one purpose: winning matches. As the #1 chassis in the PRS and the choice of thousands of competitors worldwide, its reputation is backed by countless podium finishes. This platform provides the balance, stability, and control needed to run complex stages efficiently and deliver consistent hits under extreme pressure.

The ACC Elite is designed to stay rigid when it matters most. Featuring a strengthened forend, a solid center base, and a dedicated connector bar linking the grip to the buttstock, this chassis eliminates twisting and bending during recoil or when loading into a prop.

NO IMAGE
AVAILABLE

Precision Balance: With a full-length ARCA forend and a tunable weight system, you can use MDT Weights to create a perfectly balanced rifle. This setup ensures the rifle settles fast and stays locked on target naturally under recoil.

SRS-X Elite Buttstock: Achieve a perfect, natural position behind your rifle every time. The SRS-X Elite offers fast, toolless adjustments for:
Cheek rest height (back and front)
Length-of-pull (LOP)
Buttpad height

Elite Ergonomics: The Vertical Grip - Elite allows for back, front, and angle adjustments. When paired with the adjustable M-LOK thumb rest, you get a tailored hand placement that feels completely natural.

Barricade Mastery: The included underside grip tape helps the rifle "dig in" to barricades and bags, ensuring a stable hold from the first shot to the last.

Attributes

- Name: [MDT Chassis - ACC Elite System - CZ 457 - RH - FDE](#)
- Manufacturer: [MDT](#)
- Product no.: EU2017115
- Mfr. No.: 107957-FDE
- Colour: FDE
- Model: 457
- Style: Chassis
- Weapon type: CZ
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 990482730611

Table of Contents

- [Startpage](#)
- [MDT Chassis ACC Elite System Safety Instruction Guide](#)
- [About Us](#)

MDT Chassis ACC Elite System Safety Instruction Guide

Introduction

Thank you for choosing the MDT Chassis ACC Elite System. This product is designed for high performance in competitive shooting and has been manufactured with safety in mind. This guide provides important safety instructions, general safety guidelines, and specific precautions to ensure the safe use of this product.

General Safety Guidelines

- Ensure that the MDT Chassis is used only by individuals who are trained in firearm safety and handling.
- Always treat your firearm as if it is loaded, even if you believe it is not.
- Store the chassis in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm use and ownership.
- Be aware of your surroundings and ensure that your shooting area is safe and secure.

Specific Safety Precautions for Use

- **Recoil Management:** Ensure that you are in a stable shooting position to manage recoil effectively. The chassis is designed to provide stability, but proper handling is crucial.
- **Weight Adjustments:** When using the tunable weight system, make sure all weights are securely attached before use to avoid any imbalance during shooting.
- **Adjustments:** Always perform adjustments to the SRSX Elite Buttstock and Vertical Grip when the firearm is unloaded to prevent accidental discharge.
- **Barricade Use:** When using the rifle against barricades, ensure that the underside grip tape is clean and free of debris to maintain a secure hold.
- **Environmental Awareness:** Be cautious of environmental conditions such as wind and terrain that may affect your shooting performance.

Instructions for Installation and Usage

1. Installation of the MDT Chassis:

- Begin by ensuring that the firearm is unloaded.
- Carefully attach the MDT Chassis to the firearm according to the manufacturer's guidelines.
- Ensure that all screws and connections are tightened securely.

2. Adjusting the SRSX Elite Buttstock:

- Adjust the cheek rest height by loosening the adjustment knobs and moving the cheek rest to the desired height.
- Set the lengthofpull (LOP) by adjusting the buttstock position. Ensure it is securely locked in place.
- Adjust the buttpad height to achieve a comfortable shooting position.

3. Using the Vertical Grip Elite:

- Adjust the grip angle to your preference for optimal comfort and control.
- Pair with the MLOK thumb rest for customized hand placement.

4. Weight Balancing:

- Use MDT Weights to achieve the desired balance. Start with the recommended weight and adjust as necessary for your shooting style.

5. Shooting Practice:

- Begin with dry firing to get accustomed to the chassis setup.
- Practice shooting in a safe environment, gradually increasing complexity as you become more comfortable.

Disposal Instructions

- Dispose of the MDT Chassis in accordance with local regulations.
- If the chassis is damaged beyond repair, contact local waste management for guidance on proper disposal.
- Do not dispose of the chassis in regular household waste.

Contact Information for Further Support

For any safety inquiries or further assistance, please reach out to the appropriate customer service or support channels provided by the manufacturer. Always ensure that you have the latest information regarding safety recalls or product updates.

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your MDT Chassis ACC Elite System. Always prioritize safety and responsibility in all aspects of firearm handling.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk