

AR-15/CAR-15 EXTRACTOR/EJECTOR SPRING SET - SUPERIOR SHOOTING CS EXTRACTOR/EJECTOR SPRING SET

[Rifle Parts](#) > [Triggers Parts](#) > [Trigger Hardware](#) > [Trigger Springs](#)

Stable Performance For 500,000 Compression Cycles

Replacement, drop-in fit chrome silicon extractor and ejector springs from David Tubb provide long term durability and up to 80% more power than factory springs in AR-15 rifles. Precision manufacturing and high quality steel give extremely consistent compression cycle for smooth operation over thousands of rounds.



Attributes

- Name: [SUPERIOR SHOOTING CS EXTRACTOR/EJECTOR SPRING SET](#)
- Manufacturer: [SUPERIOR SHOOTING](#)
- Product no.: 840000051
- Mfr. No.: CSSAR15
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping width: 127mm
- Shipping length: 150mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AR15/CAR15 Extractor/Ejector Spring Set
- About Us

Safety Instruction Guide for AR15/CAR15 Extractor/Ejector Spring Set

Introduction

Thank you for choosing the AR15/CAR15 Extractor/Ejector Spring Set from Superior Shooting. This product is designed to enhance the performance of your AR15 rifle with highquality chrome silicon extractor and ejector springs. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is suitable for your specific AR15 model before installation.
- Always handle firearms and related components responsibly and in accordance with local laws and regulations.
- Store the springs in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the springs for any signs of wear or damage before use.
- Report any unsafe products or incidents to the appropriate authorities and check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not exceed the recommended specifications for your rifle when installing the extractor and ejector springs.
- Avoid using damaged or worn springs, as they may pose a risk of failure during operation.
- Always wear appropriate safety gear, such as eye protection, when handling firearms.
- Ensure that the firearm is unloaded before performing any maintenance or installation work.
- Keep your workspace clean and organized to prevent accidents during installation.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials for installation.
- Ensure that your AR15 rifle is unloaded and in a safe position.

2. Installation Steps

- Remove the existing extractor and ejector springs from your AR15 rifle.
- Carefully install the new chrome silicon extractor spring by aligning it with the extractor mechanism.
- Repeat the process for the ejector spring, ensuring it is properly seated in its designated position.
- Check that both springs are securely in place before reassembling the rifle.

3. PostInstallation Check

- After installation, perform a function check to ensure that the extractor and ejector are operating smoothly.
- Test fire the rifle in a controlled environment to confirm proper functionality.

Disposal Instructions

- Dispose of any old springs or components in accordance with local waste disposal regulations.
- If the springs are damaged or unusable, consider recycling them if applicable.

Contact Information for Further Support

For any inquiries or additional support regarding the AR15/CAR15 Extractor/Ejector Spring Set, please refer to the manufacturer's contact details provided with the product packaging.

Thank you for your attention to these safety instructions. Your safety and the safe operation of your firearm are of utmost importance. Enjoy your enhanced shooting experience with the AR15/CAR15 Extractor/Ejector Spring Set from Superior Shooting!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk