

REMINGTON 700 ACTION WRENCH - SURGEON ACTION WRENCH

[Gunsmith Tools & Supplies](#) > [Rifle Tools](#) > [Wrenches](#)

Prevents Damage When Installing Barrel On Surgeon Or Remington 700 Action

Easy-to-use alternative to old-fashioned T-handle action wrenches is specifically designed to prevent damage to receiver when installing and removing barrels. Lets you torque a Remington 700 or Surgeon Rifles action as close as possible to the barrel threads to eliminate unwanted twisting or bowing of the action that can result in distorted bolt raceways and other expensive damage. Inserts in the ejection port; the two "ears" fit in the raceways at the front ring. Insert a $\frac{1}{2}$ " drive ratchet handle or torque wrench and tighten/loosen the action to the barrel. Works on any length action.



Attributes

- Name: [SURGEON ACTION WRENCH](#)
- Manufacturer: [SURGEON RIFLES](#)
- Product no.: 100003675
- Mfr. No.: N/A
- Make: Remington
- Model: 700
- Delivery weight: 0.159kg
- Shipping height: 8mm
- Shipping width: 104mm
- Shipping length: 124mm

Item details

Made in USA

Table of Contents

- Startpage
- REMINGTON 700 ACTION WRENCH SURGEON ACTION WRENCH Safety Instructions
- About Us

REMINGTON 700 ACTION WRENCH SURGEON ACTION WRENCH Safety Instructions

Introduction

Thank you for choosing the REMINGTON 700 ACTION WRENCH SURGEON ACTION WRENCH. This tool is designed to facilitate the safe installation and removal of barrels on Remington 700 and Surgeon Rifles without causing damage to the receiver. Please read this safety instruction guide carefully to ensure proper use and compliance with safety regulations.

General Safety Guidelines

- Always read and understand the product manual before use.
- Ensure the working area is clean and free from obstructions.
- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves.
- Keep the tool out of reach of children and unauthorized personnel.
- Do not exceed the maximum torque of 100 footpounds to prevent damage.
- Regularly inspect the tool for any signs of wear or damage before use.

Specific Safety Precautions for Use

- Use the tool only for its intended purpose – installing and removing barrels on Remington 700 and Surgeon Rifles.
- Ensure the action wrench is properly positioned in the ejection port and that the "ears" fit securely in the raceways.
- When using a ratchet handle or torque wrench, ensure it is compatible with the $\frac{1}{2}$ " drive.
- Avoid excessive force when tightening or loosening the action to prevent distortion or damage.
- If the tool feels stuck or resistant, stop and reassess the situation before proceeding.
- Always follow the manufacturer's instructions for any additional tools used in conjunction with the action wrench.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and safe to work on.
- Remove any existing barrels according to standard safety procedures.

2. Inserting the Action Wrench:

- Insert the action wrench into the ejection port of the firearm.
- Align the two "ears" of the wrench into the raceways located at the front ring of the action.

3. Attaching the Ratchet Handle:

- Insert a compatible $\frac{1}{2}$ " drive ratchet handle or torque wrench into the action wrench.

4. Tightening/Loosening the Action:

- To tighten: Turn the ratchet handle clockwise until the desired torque is reached, ensuring not to exceed 100 footpounds.
- To loosen: Turn the ratchet handle counterclockwise until the action is free from the barrel.

5. Final Checks:

- After installation or removal, doublecheck that all components are secure and properly aligned.
- Store the action wrench in a safe place when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of in household waste.
- If the product is damaged or no longer usable, consider recycling materials where applicable.

Contact Information for Further Support

For any questions or concerns regarding the REMINGTON 700 ACTION WRENCH SURGEON ACTION WRENCH, please refer to the manufacturer's contact information provided with the product. It is important to have access to support for any safety inquiries or product issues.

By following these safety instructions, you can ensure a safe and effective experience with the REMINGTON 700 ACTION WRENCH SURGEON ACTION WRENCH while complying with the EU General Product Safety Regulation (GPSR). Always prioritize safety and proper handling to protect yourself and others.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at