

# CZ 75, 85, P-01, PCR VORTEX VIPER/VENOM SIGHT MOUNT - EGW SIGHT MOUNT FOR VORTEX VIPER/VENOM FITS CZ75/85/P-01 BLACK

[Optics & Mounting](#) > [Rings, Mounts & Bases](#) > [Handgun Bases](#)

EGW red dot sights are meant to be installed from the left to the right (with the muzzle facing forward). The dovetail has a progressive taper to allow for easier install. Simply remove the rear sight on your gun and replace it with EGW mount in order to mount your Vortex Viper/Venom, Burris FastFire, or Docter red-dot sight. You can take the mount off and replace your rear sight at any time. Mounting hardware included. Installation Instructions Remove the rear sight\* Install the EGW Sight Mount in the dovetail Tighten set screw (if applicable) Place the red dot sight on the EGW Sight Mount (placing a small piece of paper between the red dot sight and the sight mount will make for easier removal and will keep Loctite off of the red dot sight.) Apply blue Loctite to the provided mounting screws Torque mounting screws to 15in/lbs 2 Button Head Cap Screws - Provided for Vortex Viper and Venom Sights 2 Flat Head Cap Screws - Provided for Burris FastFire and Docter Sights The screws that are included with this mount require a 5/64" allen wrench for installation. Modification of your firearm may nullify the manufacturer's warranty. This product should be installed and checked by a qualified gunsmith. No liability is expressed or implied for damage or injury which may result from improper installation or use of this product. This mount fits: CZ 75 CZ 75 SP-01 CZ 75 SP-01 Phantom CZ 75 SP-01 Shadow\* CZ 85 CZ 97B CZ 97D CZ P-01 CZ P-07 (may require fitting due to a variance in dovetail dimensions) CZ P-09 (may require fitting due to a variance in dovetail dimensions) CZ PCR (there will be a gap under the front of the adapter plate) Tristar P120



## Attributes

- Name: [EGW SIGHT MOUNT FOR VORTEX VIPER/VENOM FITS CZ75/85/P-01 BLACK](#)
- Manufacturer: [EGW](#)
- Product no.: 296000672
- Mfr. No.: 49326
- Colour: Black
- Material: Aluminum
- Model: PCR,SP-01 Phantom,97B,75,P-01,P120,85,SP-01 Shadow,P-09,P-07,SP-01,97D
- Number of Bases: 1-Piece
- Style: Tactical
- Weapon type: CZ,Tri Star
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 76mm
- Shipping length: 140mm
- UPC: 841370115860

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [CZ 75, 85, P01, PCR VORTEX VIPER/VENOM SIGHT MOUNT SAFETY INSTRUCTIONS](#)
- [About Us](#)

# CZ 75, 85, P01, PCR VORTEX VIPER/VENOM SIGHT MOUNT SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the CZ 75, 85, P01, PCR Vortex Viper/Venom Sight Mount. This guide provides essential safety instructions and installation guidelines to ensure the safe and effective use of this product. Please read this document carefully before use.

## General Safety Guidelines

- Ensure that you are familiar with the operation of your firearm and the sight mount before installation.
- Always handle firearms and accessories with care and follow all safety protocols.
- Keep the sight mount and all components out of reach of children and unauthorized users.
- Do not modify the sight mount or your firearm in any way that could compromise safety.
- Regularly inspect the sight mount for signs of wear or damage before each use.
- If you experience any issues with the sight mount, discontinue use immediately and consult a qualified gunsmith.

## Specific Safety Precautions for Use

- Only use the sight mount with compatible models listed in the product description.
- Ensure that the firearm is unloaded before beginning the installation process.
- Use the appropriate tools as specified in the installation instructions to avoid damage.
- Apply blue Loctite carefully to the mounting screws to prevent loosening during use.
- Do not exceed the specified torque of 15 in/lbs when tightening screws.
- If fitting is required for certain models, consult a qualified gunsmith to ensure proper installation.

## Instructions for Installation and Usage

1. **Remove the rear sight** from your firearm.
2. **Install the EGW Sight Mount** in the dovetail, ensuring it is oriented correctly (left to right with the muzzle facing forward).
3. **Tighten the set screw** (if applicable) to secure the mount.
4. **Place the red dot sight** on the EGW Sight Mount. For easier removal and to keep Loctite off the sight, place a small piece of paper between the red dot sight and the mount.
5. **Apply blue Loctite** to the provided mounting screws.
6. **Torque the mounting screws** to 15 in/lbs:
  - 2 Button Head Cap Screws Provided for Vortex Viper and Venom Sights
  - 2 Flat Head Cap Screws Provided for Burris FastFire and Docter Sights
7. **Inspect the installation** to ensure everything is secure before using the firearm.

## Disposal Instructions

- Dispose of the product and any packaging materials in accordance with local regulations.
- Do not dispose of the sight mount in household waste. Instead, take it to a designated waste disposal facility for proper recycling or disposal.

## Contact Information for Further Support

For any questions or concerns regarding the installation, use, or safety of the CZ 75, 85, P01, PCR Vortex Viper/Venom Sight Mount, please consult a qualified gunsmith or contact the manufacturer directly for assistance.

By adhering to these safety guidelines and instructions, you can ensure the safe use of your CZ 75, 85, P01, PCR Vortex Viper/Venom Sight Mount. Thank you for prioritizing safety and responsible firearm handling.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)