

FIRING PIN SAFETY, 9/40/357/10 - LONE WOLF DIST. FIRING PIN SAFETY, 9/40/357/10

[Handgun Parts](#) > [Safety Parts](#) > [Safeties](#)

Titanium Firing Pin Safety 25% lighter than Glock OEM part for easier trigger take up Fits all Glock 9mm, 40 S&W, 357 Sig and 10mm pistols, (Except 43)



Attributes

- Name: [LONE WOLF DIST. FIRING PIN SAFETY, 9/40/357/10](#)
- Manufacturer: [LONE WOLF DIST.](#)
- Product no.: 000002878
- Mfr. No.: LWD-84
- Delivery weight: 0.023kg
- Shipping height: 1mm
- Shipping width: 51mm
- Shipping length: 95mm

Item details

US export classification: 0A501.x

Table of Contents

- Startpage
- FIRING PIN SAFETY Instruction Manual
- About Us

FIRING PIN SAFETY Instruction Manual

Introduction

Thank you for choosing the FIRING PIN SAFETY for your Glock pistol. This product is designed to enhance the safety and performance of your firearm. Please read this manual carefully to ensure safe installation and use.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep your firearm pointed in a safe direction at all times.
- Store your firearm securely and out of reach of children.
- Use only manufacturerrecommended parts and accessories.
- Regularly inspect your firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- The FIRING PIN SAFETY is not compatible with Glock model 43. Ensure you are using it with compatible models: 9mm, 40 S&W, 357 Sig, and 10mm.
- Ensure the firearm is unloaded before installation or maintenance.
- Avoid using excessive force during installation to prevent damage to the firing pin or other components.
- Do not modify the FIRING PIN SAFETY or any other parts of your firearm.
- If you experience any malfunctions or irregularities during use, cease operation immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

Installation Steps

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: a punch tool and a small hammer.

2. Remove the Slide:

- Follow the manufacturer's instructions to safely remove the slide from your Glock pistol.

3. Remove the Old Firing Pin Safety:

- Use the punch tool to carefully push out the retaining pin holding the old firing pin safety in place.
- Remove the old firing pin safety from the slide.

4. Install the New FIRING PIN SAFETY:

- Place the new titanium FIRING PIN SAFETY in the designated slot.
- Align the retaining pin hole and insert the retaining pin using the punch tool.

5. Reassemble the Slide:

- Follow the manufacturer's instructions to reassemble the slide onto the frame of your Glock pistol.

6. Function Check:

- Perform a function check to ensure proper operation of the firing pin safety before using the firearm.

Usage Instructions

- Always follow safe handling practices when operating your firearm.
- Regularly check the FIRING PIN SAFETY for proper function as part of your routine maintenance.
- If any issues arise, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of the FIRING PIN SAFETY according to local regulations for hazardous materials.
- Do not dispose of firearm components in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the FIRING PIN SAFETY, please reach out to the manufacturer or your local firearms dealer. Ensure you have the product details ready for efficient assistance.

Important Notice: This instruction manual is designed to provide essential safety information and guidelines for the FIRING PIN SAFETY. It is crucial to adhere to all safety practices and consult professionals when in doubt. Your safety and the safety of others depend on responsible firearm ownership and usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk