

REMINGTON 870 EJECTOR SPRING RIVET CUTTER

[Gunsmith Tools & Supplies](#) > [Shotgun Tools](#) > [Shotgun Specialty Tools](#)

Trims The Rivet Tip To Make Broken Ejector Spring Removal Simple

Hollow-end mill fits in drill press, spot faces the front rivet to take off just the peened area. Often lets you re-peen the existing rivet and eliminate rebluing the receiver.



Attributes

- Name: [REMINGTON 870 EJECTOR SPRING RIVET CUTTER](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080000040
- Mfr. No.:
- Make: Remington
- Material: Steel
- Model: 870
- Delivery weight: 0.029kg
- Shipping height: 8mm
- Shipping width: 91mm
- Shipping length: 170mm
- UPC: 050806103825

Item details

Made in USA

Table of Contents

- Startpage
- REMINGTON 870 EJECTOR SPRING RIVET CUTTER Safety Instruction Guide
- About Us

REMINGTON 870 EJECTOR SPRING RIVET CUTTER

Safety Instruction Guide

Introduction

Thank you for choosing the REMINGTON 870 Ejector Spring Rivet Cutter. This tool is designed to assist in the maintenance of your shotgun by allowing for precise cutting of rivets. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always read and understand the instructions before using the tool.
- Use the tool only for its intended purpose as specified in this guide.
- Keep the tool out of reach of children and vulnerable individuals.
- Inspect the tool before each use for any signs of damage or wear.
- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when operating the tool.
- Ensure that the work area is clean and free from hazards to prevent accidents.

Specific Safety Precautions for Use

- Ensure that the drill press is securely mounted and stable before use.
- Always use the tool in a wellventilated area to avoid inhalation of dust or debris.
- Do not exceed the recommended speed settings of the drill press when using the cutter.
- Keep hands and fingers away from the cutting area while the tool is in operation.
- Do not attempt to modify or alter the tool in any way.
- If the tool becomes jammed or does not operate smoothly, turn off the drill press and disconnect it from the power source before attempting to clear the jam.

Instructions for Installation and Usage

1. Installation:

- Securely mount the drill press on a stable surface.
- Insert the hollowend mill cutter into the chuck of the drill press, ensuring it is tightly secured.
- Adjust the drill press to the appropriate speed setting as per the manufacturer's guidelines.

2. Usage:

- Position the shotgun receiver securely on the work surface.
- Align the cutter with the front rivet that needs to be cut.
- Turn on the drill press and gradually lower the cutter onto the rivet, applying light pressure.
- Monitor the cutting process closely to ensure precision and avoid overcutting.
- Once the rivet is cut, turn off the drill press and remove the cutter from the receiver.

Disposal Instructions

- Dispose of the tool responsibly at the end of its life cycle.
- Follow local regulations for the disposal of metal tools and components.
- Do not dispose of the tool in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the REMINGTON 870 Ejector Spring Rivet Cutter, please refer to the manufacturer's contact information provided with the product packaging.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the REMINGTON 870 Ejector Spring Rivet Cutter. Always prioritize safety and adhere to the guidelines provided to maintain your wellbeing and that of others around you.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at