

# **EXTRA-WIDE SPRING STEEL - 1"X1/32" EXTRA-WIDE SPRING STEEL STOCK 4 PACK**

[Gunsmith Tools & Supplies](#) > [Small Hardware](#) > [Bulk Spring Kits](#)

## **Two Widths & Three Thicknesses For Custom Springs & Parts**

Big enough to make those wide springs on new and old muzzleloaders, double rifles and shotguns; parts too.



## **Attributes**

- Name: [1"X1/32" EXTRA-WIDE SPRING STEEL STOCK 4 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080038132
- Mfr. No.:
- Length: 16 in
- Quantity: 4
- Delivery weight: 0.272kg
- Shipping height: 8mm
- Shipping width: 81mm
- Shipping length: 427mm
- UPC: 050806012028

## **Item details**

Made in USA

# Table of Contents

- Startpage
- EXTRAWIDE SPRING STEEL 1"X1/32" EXTRAWIDE SPRING STEEL STOCK 4 PACK Safety Instruction Guide
- About Us

# EXTRAWIDE SPRING STEEL 1"X1/32" EXTRAWIDE SPRING STEEL STOCK 4 PACK Safety Instruction Guide

## Introduction

Thank you for choosing the EXTRAWIDE SPRING STEEL 1"X1/32" EXTRAWIDE SPRING STEEL STOCK 4 PACK. This guide provides essential safety instructions to ensure safe usage of this product. Please read this document carefully to understand how to handle and use the product safely.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always wear appropriate personal protective equipment (PPE) such as gloves and safety glasses when handling the steel stock.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear before use.
- Store the product in a dry place to prevent corrosion.
- Report any unsafe conditions or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- Avoid direct contact with skin to prevent cuts or abrasions.
- When cutting or shaping the steel, ensure that the work area is clear of unnecessary personnel.
- Use appropriate tools designed for working with spring steel to avoid accidents.
- Be cautious of sharp edges and points when handling the steel stock.
- Follow proper procedures when heating the steel to avoid burns and other injuries.

## Instructions for Installation and Usage

### 1. Preparation:

- Gather all necessary tools and materials before starting your project.
- Ensure your workspace is clean and welllit.

### 2. Cutting the Steel:

- Use a metal cutting saw or shears designed for steel.
- Measure and mark the desired length on the steel before cutting.
- Secure the steel in a vice or clamp to prevent movement during cutting.

### 3. Shaping the Steel:

- Use appropriate tools such as hammers or bending jigs to shape the steel.
- Always wear safety gloves and goggles during this process.

### 4. Hardening the Steel:

- Heat the steel to a temperature of 1450°1500° F using a forge or furnace.
- Once heated, quench the steel in oil to harden it.
- Allow the steel to cool completely before handling.

### 5. Final Inspection:

- Check the finished product for any defects or sharp edges.
- Smooth any rough edges using a file or grinder as necessary.

## **Disposal Instructions**

- Dispose of any scrap pieces of steel responsibly.
- Follow local regulations for metal recycling or disposal.
- Ensure that all waste materials are disposed of in a safe manner to prevent injury to others.

## **Contact Information for Further Support**

For any inquiries regarding safety or product information, please refer to the manufacturer's website or contact your local distributor.

By following these safety instructions, you can ensure a safe and effective experience with the EXTRAWIDE SPRING STEEL 1"X1/32" EXTRAWIDE SPRING STEEL STOCK 4 PACK. Always prioritize safety and report any concerns regarding the product.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)