

# FIRING PIN PROTRUSION GAUGE - AR-15/M16 FIRING/PIN GAUGE

[Gunsmith Tools & Supplies](#) > [Measuring Tools](#) > [Firing Pin Protrusion Gauges](#)

Essential for properly measuring the amount of the firing pin projecting through the bolt. Too little causes misfires; too much, pierced primers.



## Attributes

- Name: [AR-15/M16 FIRING/PIN GAUGE](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080216013
- Mfr. No.:
- Delivery weight: 0.009kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806101678

## Item details

Made in USA

# Table of Contents

- Startpage
- FIRING PIN PROTRUSION GAUGE AR15/M16 Safety Instruction Guide
- About Us

# FIRING PIN PROTRUSION GAUGE AR15/M16 Safety Instruction Guide

## Introduction

Thank you for purchasing the Firing Pin Protrusion Gauge AR15/M16. This tool is essential for accurately measuring the firing pin's projection through the bolt. Proper measurement is critical to ensure the safe functioning of your firearm, preventing misfires and pierced primers. This safety instruction guide provides important information to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Ensure safe use of the Firing Pin Protrusion Gauge by following these guidelines:
  - Always read and understand the instructions before use.
  - Use the gauge only for its intended purpose.
  - Keep the gauge out of reach of children and vulnerable individuals.
  - Regularly inspect the gauge for any signs of wear or damage.
  - Report any unsafe conditions or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- When using the Firing Pin Protrusion Gauge, please observe the following precautions:
  - Wear appropriate safety gear, such as safety glasses, when measuring.
  - Ensure the firearm is unloaded and in a safe condition before measurement.
  - Do not force the gauge into the bolt; it should fit snugly but not require excessive pressure.
  - Avoid using the gauge in wet or humid conditions to prevent rust and corrosion.
  - If the gauge is damaged or shows signs of wear, discontinue use immediately.

## Instructions for Installation and Usage

- Follow these steps to ensure proper installation and usage of the Firing Pin Protrusion Gauge:

### 1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools and safety equipment.

### 2. Measurement:

- Insert the gauge into the bolt where the firing pin protrudes.
- Ensure the gauge is seated firmly but not forced.
- Read the measurement displayed on the gauge.
- Compare the measurement against the manufacturer's specifications for your firearm.

### 3. PostMeasurement:

- Carefully remove the gauge from the bolt.
- Clean the gauge after use to maintain its accuracy and longevity.

### 4. Storage:

- Store the gauge in a dry, safe place, away from children and unauthorized users.

## Disposal Instructions

- When the Firing Pin Protrusion Gauge reaches the end of its useful life, dispose of it responsibly:
  - Check local regulations for proper disposal methods of metal products.
  - Do not dispose of the gauge in regular household waste.
  - If the gauge is damaged beyond repair, consider recycling the metal components.

## Contact Information for Further Support

- For any questions or concerns regarding the Firing Pin Protrusion Gauge, please consult your local distributor or manufacturer. They can provide assistance and further information about safety and usage.

By adhering to these safety guidelines and instructions, you can ensure the safe and effective use of the Firing Pin Protrusion Gauge AR15/M16. Thank you for prioritizing safety in your firearm maintenance practices.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)