BERETTA RECOIL SPRING - 14 LB. CS BERETTA SPRING

Designed For Maximum Consistency & Reliability

CAD designed and built to aerospace specifications from chrome silicon, corrosion resistant, stainless steel or chrome vanadium for maximum durability, consistency and reliable performance. Built to aerospace specifications; heat treated, shot peened and fully stress relieved to minimize spring set. BERETTA RECOIL SPRING - Chrome silicon (CS) springs wound for 14 and 16 lb. Beretta Models 92 & 96.

Attributes

- Name: [14 LB. CS BERETTA SPRING](#)
- Manufacturer: [ISMI](#)
- Product no.: 100002626
- Mfr. No.: 92R-14
- Make: Beretta
- Model: 92,96
- Pounds: 14 lbs
- Delivery weight: 0.005kg
- Shipping height: 6mm
- Shipping width: 76mm
- Shipping length: 203mm

Item details

Made in USA

Table of Contents

BERETTA RECOIL SPRING 14 LB. CS BERETTA SPRING Safety Instructions

Introduction

Thank you for purchasing the Beretta Recoil Spring 14 lb. CS Beretta Spring. This product is designed for maximum durability and reliable performance. To ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR), please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the recoil spring is compatible with your firearm model (Beretta Models 92 & 96).
- Always handle firearms with care and follow all local laws and regulations regarding firearm usage.
- Store the recoil spring in a dry, cool place, away from direct sunlight and moisture.
- Do not use the recoil spring if it shows signs of damage or wear.
- Regularly check the recoil spring for any signs of corrosion or fatigue.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the recoil spring with firearms that are specifically designed for it.
- Ensure that you are familiar with the operation of your firearm before installation.
- Always wear appropriate eye protection when handling or working with firearms.
- Keep the working area clear of distractions and unauthorized personnel.
- Do not modify the recoil spring in any way, as this may compromise its safety and performance.
- If you are inexperienced with firearm maintenance, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. **Preparation**

   - Ensure the firearm is unloaded and pointed in a safe direction.
   - Gather necessary tools for installation, if required (e.g., screwdriver, pliers).

2. **Installation**

   - Remove the old recoil spring from the firearm, following the manufacturer's instructions.
   - Inspect the new recoil spring for any visible defects before installation.
   - Carefully install the new recoil spring into the firearm, ensuring it is seated correctly as per the manufacturer's guidelines.

3. **PostInstallation Check**

   - After installation, perform a function check of the firearm to ensure proper operation.
   - Store the firearm in a secure location when not in use.

4. **Usage**

   - Always follow safe handling procedures when using your firearm.
   - Regularly inspect the recoil spring during routine firearm maintenance.

Disposal Instructions

- Dispose of any damaged or worn recoil springs in accordance with local regulations.
- Do not dispose of recoil springs in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Beretta Recoil Spring 14 lb. CS Beretta Spring, please contact the manufacturer or consult the product packaging for further support information.

By following these safety instructions, you can help ensure safe and effective use of the Beretta Recoil Spring. Thank you for your attention to safety and for choosing our product.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at