

LOAD-MASTER PROGRESSIVE PRESSES - LEE PRECISION 38 SPECIAL/357 MAGNUM LOAD-MASTER PROGRESSIVE PRESS

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Lee Load-Master progressive 5-hole reloading kit includes full length sizing die, powder through expanding die, bullet seating die, turret, shell plate, Auto-Drum Powder Measure, case feeder and primer feed. The Load-Master Progressive Press Only does not include Case feeder, Dies, Shell Plate, Primer Feed or Powder measure. These items must be purchased separately.



Attributes

- Name: [LEE PRECISION 38 SPECIAL/357 MAGNUM LOAD-MASTER PROGRESSIVE PRESS](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100032123
- Mfr. No.: 90938
- Cartridge: 357 Magnum,38 Special
- Delivery weight: 6.895kg
- Shipping height: 229mm
- Shipping width: 279mm
- Shipping length: 483mm
- UPC: 734307909383

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for the Lee LoadMaster Progressive Press
- About Us

Safety Instruction Guide for the Lee LoadMaster Progressive Press

Introduction

Thank you for choosing the Lee LoadMaster Progressive Press for your reloading needs. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read and follow these instructions carefully to minimize risks and ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the work area is clean, welllit, and free from distractions.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the press.
- Keep the press out of reach of children and pets to prevent accidents.
- Only use the press for its intended purpose: reloading cartridges for the 38 Special and 357 Magnum.
- Regularly inspect the equipment for any signs of wear or damage before use.
- Follow all manufacturer instructions and guidelines provided with the equipment.

Specific Safety Precautions for Use

- **Hazardous Materials:** Reloading involves the use of gunpowder and primers, which can be hazardous. Handle these materials with care and store them in a safe, cool, and dry place.
- **Avoid Overloading:** Do not exceed the recommended load specifications for the cartridges you are reloading.
- **Ventilation:** Ensure proper ventilation in your work area to avoid inhaling fumes from gunpowder or other materials.
- **DistractionFree Environment:** Avoid distractions while operating the press to maintain focus and prevent accidents.
- **Emergency Preparedness:** Keep a fire extinguisher rated for flammable materials nearby in case of an emergency.

Instructions for Installation and Usage

1. **Unpacking the Press:** Carefully remove the press and all components from the packaging. Ensure that all parts are present and undamaged.
2. **Assembly:**
 - Follow the manufacturer's assembly instructions included in the packaging.
 - Ensure that all screws and bolts are tightened securely.
3. **Setup:**
 - Place the press on a sturdy, stable workbench to prevent tipping or movement during operation.
 - Ensure that the press is level and securely fastened to the workbench if necessary.
4. **Die Installation:**
 - Install the fulllength sizing die, powder through expanding die, and bullet seating die as per the manufacturer's instructions.
 - Ensure that dies are properly adjusted for the specific cartridge being reloaded.
5. **Powder Measure Setup:**
 - Attach the AutoDrum Powder Measure according to the instructions provided.
 - Calibrate the powder measure to ensure accurate powder charges.
6. **Loading Process:**
 - Begin the reloading process by following the stepbystep instructions provided by the manufacturer.

- Monitor the process closely, and do not leave the press unattended while in operation.

7. Cleaning and Maintenance:

- After use, clean the press and all components to prevent residue buildup.
- Regularly inspect and lubricate moving parts as recommended by the manufacturer.

Disposal Instructions

- Dispose of any unused or excess materials (e.g., gunpowder, primers) in accordance with local regulations for hazardous waste.
- Do not throw away reloading components in regular trash. Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the safety and use of the Lee LoadMaster Progressive Press, please refer to the manufacturer's official website or customer service for assistance.

By following these guidelines, you can ensure a safe and efficient reloading experience with the Lee LoadMaster Progressive Press. Always prioritize safety and adhere to the instructions provided. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk