

# AR-15 HANDGUARDS M-LOK 5.56MM - FORWARD CONTROLS DESIGN AR-15 HANDGUARD 13.7IN. M-LOK BLACK

[Rifle Parts](#) > [Build Kits](#) > [Handguards & Rails](#)

AR-15 HANDGUARDS M-LOK 5.56MM RHF (Railed Handguard, Forward Controls) is based on the superb CMT UHPR Mod2, with full length 1913 rails at 12 o'clock, and MLOK at 3, 6, and 9 o'clock. RHF is machined from 6000 series extruded aluminum, its barrel nut is machined from 7075 aluminum, both are Type 3 anodized, while the rail mounting hardware is machined from 17-4 PH (patent pending). RHF also incorporates anti-rotation tabs. RHF's inside diameter is 1.315" and compatible with most low-profile gas blocks. Barrel nut diameter is 1.378", barrel nut wrench is included. SPECS: Barrel nut torque: milspec 40-70ft/lbs Rail clamp screws torque: 45 inc/lbs. AR15/M16 free float handguards Full length 1913 rail at 12 o'clock MLOK at 3, 6 and 9 o'clock Available lengths: 6.7", 12.7" and 13.7". Weight by length: .45 lb, .7 lb and .725 lb RHF incorporates design input from Forward Controls, the changes include: Barrel cooling vents changed to the classic round shape. One might say they're paying homage to Knight's Armament's RAS and RIS where meaningful modular revolution began. Simplification of the already understated aesthetics of the CMT UHPR Mod 2 handguard.



## Attributes

- Name: [FORWARD CONTROLS DESIGN AR-15 HANDGUARD 13.7IN. M-LOK BLACK](#)
- Manufacturer: [FORWARD CONTROLS DESIGN](#)
- Product no.: 100044425
- Mfr. No.: RHF, 13.7
- Colour: Black
- Length: 13.7
- Material: Aluminum
- Style: M-LOK
- Type: Free Float
- Weapon type: AR-15
- Delivery weight: 0.59kg
- Shipping height: 108mm
- Shipping width: 114mm
- Shipping length: 425mm
- UPC: 680665827145

## Item details

Made in USA

US export classification: 0A501.y.1

# Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for AR15 Handguards MLOK 5.56mm](#)
- [About Us](#)

# Safety Instruction Guide for AR15 Handguards MLOK 5.56mm

## Introduction

Thank you for choosing the AR15 Handguards MLOK 5.56mm by Forward Controls Design. This guide provides essential safety instructions, installation guidance, and disposal information to ensure the safe and effective use of your handguard. Please read this manual carefully before use.

## General Safety Guidelines

- Ensure that the product is used in accordance with all applicable laws and regulations.
- Always wear appropriate safety gear, such as eye protection, when handling or installing the handguard.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the handguard and its components for wear or damage before use.
- If you notice any defects or issues, discontinue use and seek professional advice.
- Report any unsafe products or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- **Installation:** Follow the installation instructions carefully to avoid improper fitting that may lead to accidents.
- **Compatibility:** Ensure that the handguard is compatible with your AR15 model. Refer to the specifications provided.
- **Torque Specifications:** Adhere to the specified torque settings for the barrel nut and rail clamp screws to prevent loosening during use.
- **Heat Management:** Be aware that the handguard may become hot during use. Allow it to cool before handling.
- **Modifications:** Do not modify the handguard or its components, as this may compromise safety and performance.
- **Storage:** Store the handguard in a dry, cool place when not in use to prevent corrosion and damage.

## Instructions for Installation and Usage

### Installation Steps

#### 1. Preparation:

- Gather all necessary tools, including a barrel nut wrench and torque wrench.
- Ensure your workspace is clean and free of obstructions.

#### 2. Remove Existing Handguard:

- Follow the manufacturer's instructions for removing the existing handguard from your AR15.

#### 3. Install Barrel Nut:

- Place the barrel nut onto the upper receiver.
- Use the barrel nut wrench to tighten the barrel nut to the specified torque of 4070 ft/lbs.

#### 4. Attach Handguard:

- Align the handguard with the barrel nut and slide it into place.
- Secure the handguard using the provided rail clamp screws, tightening them to a torque of 45

in/lbs.

#### **5. Final Inspection:**

- Check that the handguard is securely attached and does not move.
- Inspect for any visible gaps or misalignments.

### **Usage Guidelines**

- Ensure that you are familiar with the operation of your AR15 before using the handguard.
- Regularly clean and maintain the handguard to ensure optimal performance.
- Avoid using the firearm in conditions that may compromise safety, such as inclement weather or rough terrain.

### **Disposal Instructions**

- Dispose of the handguard and its components in accordance with local regulations.
- Recycle materials where possible, such as aluminum and packaging materials.
- Do not dispose of the handguard in regular household waste if it is damaged or contains hazardous materials.

### **Contact Information for Further Support**

For any questions or concerns regarding the AR15 Handguards MLOK 5.56mm, please refer to the manufacturer's contact information provided with your product. Always ensure that you have access to support for safe usage and maintenance of your handguard.

Thank you for taking the time to read this safety instruction guide. Your safety and satisfaction are our top priorities. Enjoy your new AR15 Handguards MLOK 5.56mm responsibly!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)