

# AR-15 BARREL NUT - SONS OF LIBERTY GUN WORKS BARREL NUT FOR AR-15

[Rifle Parts](#) > [Barrel Parts](#) > [Rifle Barrel Hardware](#) > [Barrel Nuts](#)

Sons of Liberty Gun Works factory OEM Barrel Nut for Mil-Spec AR-15s.



## Attributes

- Name: [SONS OF LIBERTY GUN WORKS BARREL NUT FOR AR-15](#)
- Manufacturer: [SONS OF LIBERTY GUN WORKS](#)
- Product no.: 100045043
- Mfr. No.: BARRELNUT
- Weapon type: AR-15
- Delivery weight: 0.036kg
- Shipping height: 25mm
- Shipping width: 70mm
- Shipping length: 114mm
- UPC: 785939517798

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Barrel Nut
- About Us

# Safety Instruction Guide for AR15 Barrel Nut

## Introduction

Thank you for choosing the Sons of Liberty Gun Works Barrel Nut for your AR15. This guide provides essential safety instructions to ensure safe use and installation of the product. Please read and follow these guidelines carefully to ensure your safety and the optimal performance of your firearm.

## General Safety Guidelines

- Always handle firearms with care and respect.
- Ensure the firearm is unloaded before installing or handling the barrel nut.
- Store the barrel nut and all firearm components in a secure location, out of reach of children.
- Always wear appropriate safety gear, including eye protection, when working with firearms.
- Be aware of your surroundings and ensure you are in a safe environment when using the firearm.
- Regularly check for recalls or safety notices related to your firearm and its components.

## Specific Safety Precautions for Use

- Use only compatible parts with your AR15 to avoid malfunctions.
- Inspect the barrel nut for any signs of damage before installation.
- Do not exceed recommended torque specifications when installing the barrel nut.
- Ensure that all tools used for installation are in good condition and suitable for the task.
- If you are not familiar with firearm assembly or disassembly, seek assistance from a qualified gunsmith.

## Instructions for Installation and Usage

### 1. Preparation

- Gather all necessary tools including a torque wrench, barrel nut wrench, and any other required tools.
- Ensure your workspace is clean and organized.

### 2. Installation Steps

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing barrel nut if applicable, using the appropriate tools.
- Clean the threads of the barrel and the new barrel nut to ensure a proper fit.
- Align the new barrel nut with the barrel threads and handtighten it.
- Use a barrel nut wrench to tighten the barrel nut to the manufacturer's specifications. Avoid overtightening.
- Reassemble the firearm according to the manufacturer's instructions.

### 3. PostInstallation Checks

- After installation, check the alignment and fit of the barrel nut.
- Perform a function check of the firearm to ensure it operates correctly.

## Disposal Instructions

- Dispose of any packaging materials responsibly, following local regulations.
- If the barrel nut is damaged or no longer needed, dispose of it in accordance with local waste disposal regulations.
- Do not throw away any parts that may be considered hazardous or that could cause injury.

## Contact Information for Further Support

For any safety inquiries or additional support, please refer to the relevant contact points provided by the manufacturer or your local authorities. Always ensure that you have up-to-date information regarding product safety and recalls.

## Conclusion

By following these safety instructions, you can ensure the safe use and installation of the Sons of Liberty Gun Works Barrel Nut for your AR15. Always prioritize safety and seek professional assistance when needed. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)