

1911 GOVERNMENT 9MM DUAL RECOIL SPRING - COLT 1911 RECOIL SPRING GOVERNMENT 9MM OUTER

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Advanced Dual-Spring System Gives You a Softer-Recoiling, More Reliable Pistol

These are replacement inner and outer recoil springs for Colt 1911 pistols chambered in 9mm Luger that use the new Colt Dual Spring Recoil System™ originally developed in 2011 for the USMC M45A1 pistol. The inner and outer springs work together to provide enhanced reliability and extended recoil spring service life up to 15,000 rounds. (The standard interval for replacing standard 1911 recoil springs is 5,000 rounds.) This longer service life is particularly helpful to high-volume shooters who shoot their pistols A LOT, military and law enforcement personnel, as well as competition shooters.



Other benefits of the dual recoil spring system are a gentler recoil impulse (which aids in accurate shooting) and more reliable feeding of rounds from the magazine. Tempered spring steel Correct spring tension for 9mm ammo Use ONLY in Colt 1911 Government Model (full-sized) pistols or clones chambered in 9mm Other required components sold separately (described below) These inner and outer recoil springs must be used in conjunction with the other two parts of the Colt Dual Spring Recoil System™: a dedicated guide rod and recoil spring plug.

Attributes

- Name: [COLT 1911 RECOIL SPRING GOVERNMENT 9MM OUTER](#)
- Manufacturer: [COLT](#)
- Product no.: 160000447
- Mfr. No.: 300556
- Model: Government
- Weapon type: 1911
- Delivery weight: 0.454kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Government 9MM Dual Recoil Spring
- About Us

Safety Instruction Guide for 1911 Government 9MM Dual Recoil Spring

Introduction

Thank you for purchasing the 1911 Government 9MM Dual Recoil Spring. This product is designed to enhance the performance and reliability of your Colt 1911 pistol chambered in 9mm Luger. It is important to follow the safety instructions outlined in this guide to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle firearms with care and ensure they are pointed in a safe direction.
- Keep the firearm unloaded when not in use.
- Ensure you are familiar with the operation of your Colt 1911 pistol before using this product.
- Store all firearm components, including recoil springs, in a secure place out of reach of children.
- Regularly inspect the recoil springs for signs of wear or damage before installation.
- Follow all local laws and regulations regarding firearm use and maintenance.

Specific Safety Precautions for Use

- Use ONLY in Colt 1911 Government Model (full-sized) pistols or clones chambered in 9mm.
- Ensure that the recoil springs are installed correctly as per the instructions provided.
- Do not use this product with ammunition other than 9mm Luger.
- Avoid excessive force during installation to prevent damage to the recoil springs or the firearm.
- If you experience any issues with the recoil springs, discontinue use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Gather Required Tools:

- A dedicated guide rod
- A recoil spring plug
- A suitable workspace with adequate lighting

2. Remove the Existing Recoil Springs:

- Ensure the firearm is unloaded.
- Disassemble the Colt 1911 as per the manufacturer's instructions.
- Carefully remove the existing recoil springs from the guide rod.

3. Install the Inner and Outer Recoil Springs:

- Place the inner recoil spring onto the guide rod.
- Follow with the outer recoil spring, ensuring it fits snugly over the inner spring.
- Ensure the springs are oriented correctly as per the manufacturer's specifications.

4. Reassemble the Firearm:

- Replace the recoil spring plug and ensure it is secured.
- Reassemble the firearm according to the manufacturer's instructions.
- Conduct a function check to ensure proper operation.

5. Regular Maintenance:

- Inspect the recoil springs after every 1,000 rounds or if you notice any performance issues.
- Replace the recoil springs after 15,000 rounds for optimal performance.

Disposal Instructions

- Dispose of any damaged or worn recoil springs in accordance with local regulations.
- Do not dispose of the recoil springs in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the 1911 Government 9MM Dual Recoil Spring, please refer to the manufacturer's contact information included in your product packaging.

Conclusion

By following these safety instructions and guidelines, you can ensure the safe and effective use of your 1911 Government 9MM Dual Recoil Spring. Always prioritize safety and compliance with local laws when handling firearms. Thank you for choosing our product, and we wish you safe and enjoyable shooting experiences.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk