

# MANDRELS - CRATEX #6 POINT MANDREL (3)

[Gunsmith Tools](#) > [Power Tools & Accessories](#) > [Rubber Abrasive Tools](#) > [Rubber Abrasive Accessories](#)

#4 Point Mandrel, 1/8" shank diameter, fits 1/16" (1.59mm) arbor hole. #6 Point Mandrel, 1/8" shank diameter fits 1/8" arbor hole. 25,000 rpm max. Mandrels sold 3 each per pkg. Try-Pak contains 1 of each size.



## Attributes

- Name: [CRATEX #6 POINT MANDREL \(3\)](#)
- Manufacturer: [CRATEX](#)
- Product no.: 190001006
- Mfr. No.:
- Delivery weight: 0.009kg
- Shipping width: 83mm
- Shipping length: 146mm

# Table of Contents

- Startpage
- MANDRELS CRATEX #6 POINT MANDREL (3) Safety Instruction Guide
- About Us

# MANDRELS CRATEX #6 POINT MANDREL (3)

## Safety Instruction Guide

### Introduction

Thank you for purchasing the MANDRELS CRATEX #6 POINT MANDREL (3). This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read and follow these guidelines carefully to minimize any risks associated with its use.

### General Safety Guidelines

- Always ensure that the mandrel is compatible with your tools and accessories.
- Inspect the mandrel for any signs of damage or wear before each use.
- Use the mandrel only for its intended purpose, as specified in this guide.
- Keep the mandrel and all related accessories out of reach of children and vulnerable individuals.
- Follow local regulations and guidelines for the disposal of abrasive materials.

### Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety goggles and gloves when handling and using the mandrel.
- Ensure that the maximum RPM of 25,000 is not exceeded during operation to prevent breakage or injury.
- Do not use the mandrel if it is damaged or if the shank does not fit securely in your tool.
- Avoid contact with the rotating mandrel during operation to prevent injury.
- Always operate the mandrel in a wellventilated area to minimize inhalation of dust and debris.

### Instructions for Installation and Usage

#### 1. Installation:

- Ensure that the power tool is turned off and unplugged before installation.
- Select the appropriate mandrel size for your application (either #4 Point or #6 Point).
- Insert the mandrel's shank (1/8" diameter) securely into the arbor hole of your tool (1/16" for #4 Point or 1/8" for #6 Point).
- Tighten the tool's chuck securely to hold the mandrel in place.

#### 2. Usage:

- Turn on the power tool and allow the mandrel to reach the desired speed before making contact with the workpiece.
- Apply light pressure when using the mandrel to avoid overloading the tool and the mandrel.
- Maintain a firm grip on the tool and keep both hands clear of the rotating mandrel.
- If the mandrel becomes clogged or shows signs of wear, stop the tool and replace the mandrel as necessary.

### Disposal Instructions

- Dispose of used mandrels and abrasive materials in accordance with local regulations.
- Do not dispose of mandrels in regular household waste. Check with local waste management for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the safety and use of the MANDRELS CRATEX #6 POINT MANDREL (3), please refer to the manufacturer's contact information provided on the packaging or product insert.

Thank you for your attention to these safety guidelines. Your safety is our priority.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)