

WHEELS - CRATEX WHEEL, FINE, #74 WHEEL, 1/16" ARBOR

[Gunsmith Tools](#) > [Power Tools & Accessories](#) > [Rubber Abrasive Tools](#) > [Rubber Abrasive Wheels](#)

#74 Straight Edge Wheel, 7/8" (22.2mm) diameter, 1/8" thick. #86 Straight Edge Wheel, 1" diameter, 3/16" (4.76mm) thick.



Attributes

- Name: [CRATEX WHEEL, FINE, #74 WHEEL, 1/16" ARBOR](#)
- Manufacturer: [CRATEX](#)
- Product no.: 190025743
- Mfr. No.:
- Delivery weight: 0.082kg
- Shipping height: 10mm
- Shipping width: 79mm
- Shipping length: 130mm

Table of Contents

- Startpage
- Safety Instructions for WHEELS CRATEX WHEEL, FINE, #74 WHEEL, 1/16" ARBOR
- About Us

Safety Instructions for WHEELS CRATEX WHEEL, FINE, #74 WHEEL, 1/16" ARBOR

Introduction

Thank you for choosing the WHEELS CRATEX WHEEL, FINE, #74 WHEEL, 1/16" ARBOR. This product is designed for use in various applications requiring precision and durability. To ensure your safety and the longevity of the product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Ensure that all safety equipment is worn, including eye protection and gloves, when using the wheels.
- Keep the work area clean and welllit to prevent accidents.
- Do not use the wheels for purposes other than those specified by the manufacturer.
- Be aware of your surroundings and ensure that bystanders are at a safe distance while operating the tool.
- Regularly inspect the wheels for wear and damage before use.

Specific Safety Precautions for Use

- Use the wheels only on compatible tools with the correct arbor size (1/16").
- Do not exceed the maximum operating speed specified for the wheels.
- Avoid using the wheels on materials that may produce hazardous dust or fumes.
- Do not use damaged wheels; replace them immediately.
- Ensure that the wheels are securely mounted before use.
- Be cautious of sharp edges and hot surfaces during and after use.

Instructions for Installation and Usage

1. Installation:

- Ensure the tool is unplugged or powered off before installation.
- Remove any existing wheels from the tool.
- Align the wheel with the arbor and securely attach it, ensuring it is properly seated.
- Tighten the mounting nut according to the tool's specifications.
- Doublecheck that the wheel is securely attached before powering on the tool.

2. Usage:

- Start the tool at a low speed to ensure the wheel is functioning correctly.
- Gradually increase the speed as needed, but do not exceed the recommended maximum speed.
- Apply light pressure when using the wheel; excessive force can lead to damage or injury.
- Allow the wheel to come to a complete stop before removing it from the workpiece.
- Clean the work area and the tool after use to prevent debris buildup.

Disposal Instructions

- Dispose of the wheels in accordance with local regulations for hazardous waste.
- Do not dispose of the wheels in regular household waste.
- Check with local authorities for specific disposal guidelines related to abrasive materials.

Contact Information for Further Support

For any safety inquiries or additional support regarding the WHEELS CRATEX WHEEL, please refer to the contact details provided with your product packaging or visit the manufacturer's website.

By adhering to these safety instructions, you can ensure a safe and effective experience while using the WHEELS CRATEX WHEEL, FINE, #74 WHEEL, 1/16" ARBOR. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk