

RIFLE POLYMER SPACER - 100 STRAIGHT PRODUCTS 1/8" POLYMER SPACER WHITE POLYMER

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Buttstock Spacers](#)

Great Looking Spacers; Easy To Fit, Grind & Finish

Jet black or bright white, buttstock spacers made from strong, lightweight, polymer plastic for superior sanding and machining characteristics. Slotted hole design makes it easy to match up with just about any hole location. The wide range of thicknesses available let you use them alone or in combination to adjust rifle or shotgun stocks for length of pull, or to add a decorative and finishing touch to the stock.



Attributes

- Name: [100 STRAIGHT PRODUCTS 1/8" POLYMER SPACER WHITE POLYMER](#)
- Manufacturer: [100 STRAIGHT PRODUCTS](#)
- Product no.: 365101125
- Mfr. No.: 01400S118W
- Finish: White
- Material: Polymer
- Size: 5-7/8 in.
- Delivery weight: 0.014kg
- Shipping height: 5mm
- Shipping width: 130mm
- Shipping length: 135mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for RIFLE POLYMER SPACER 100 STRAIGHT PRODUCTS
- About Us

Safety Instruction Guide for RIFLE POLYMER SPACER 100 STRAIGHT PRODUCTS

Introduction

Thank you for choosing the RIFLE POLYMER SPACER from 100 STRAIGHT PRODUCTS. This guide provides essential safety information and instructions to ensure the safe use and installation of the polymer spacers. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose, which is to adjust rifle or shotgun stocks for length of pull.
- Always inspect the polymer spacers for any visible damage or defects before installation. Do not use damaged spacers.
- Keep the spacers out of reach of children and vulnerable individuals to prevent accidental injury.
- If you experience any issues or concerns while using the product, stop using it immediately and seek assistance.

Specific Safety Precautions for Use

- Do not exceed the recommended thicknesses of 1/8" (3.17mm), 1/4" (6.35mm), and 1/2" (12.7mm) when stacking spacers.
- Ensure that the spacers are properly aligned with the buttstock before securing them in place.
- Use appropriate tools when installing the spacers to avoid injury and ensure a secure fit.
- Avoid using excessive force when tightening screws or fittings to prevent damage to the spacers or the buttstock.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools, including a screwdriver and any other tools specified by the manufacturer.
- Ensure that the area where you will be working is clean and free of distractions.

2. Installation

- Remove the existing buttstock from your rifle or shotgun if applicable.
- Align the polymer spacer with the desired hole locations on the buttstock.
- Use the slotted holes to adjust the position of the spacer as needed.
- Secure the spacer in place using the appropriate screws or fasteners. Ensure they are tightened adequately but do not overtighten.

3. Usage

- Once installed, check the stability of the spacer by gently pulling on it to ensure it is securely attached.
- Test the length of pull by shouldering the firearm to ensure comfort and proper fit.

Disposal Instructions

- Dispose of any damaged or unused spacers in accordance with local regulations for plastic waste.
- Do not burn the spacers as they are made from polymer plastic, which can release harmful fumes when incinerated.

Contact Information for Further Support

For any inquiries regarding safety or product concerns, please contact the manufacturer directly through their designated EUbased contact point.

Thank you for following these safety instructions. We hope you enjoy using your RIFLE POLYMER SPACER safely and effectively.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk