

RIFLE PRO MICROMETER SEATING DIES - LYMAN 300 BLACKOUT PRO MICROMETER SEATING DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Our Micrometer Seating Die gives you exact bullet seating length and minimal run-out. The seating die has a micrometer adjustable seating head for precision bullet seating length. If you want to change your bullet seating depth a few thousandths of an inch, simply turn the micrometer head to the required setting. Its floating bullet seating punch centers the bullet on the case and eliminates excessive run-out. Our Micrometer Seating die is also made of corrosion resistant stainless steel which protects it from rust and keeps it looking like new for a lifetime of use.



Attributes

- Name: [LYMAN 300 BLACKOUT PRO MICROMETER SEATING DIE](#)
- Manufacturer: [LYMAN](#)
- Product no.: 539000254
- Mfr. No.: 7704410
- Cartridge: 300 AAC Blackout
- Die Style: Seater Die
- Delivery weight: 0.358kg
- Shipping height: 51mm
- Shipping width: 51mm
- Shipping length: 152mm
- UPC: 011516744104

Item details

Made in USA

Table of Contents

- Startpage
- RIFLE PRO MICROMETER SEATING DIES SAFETY INSTRUCTIONS
- About Us

RIFLE PRO MICROMETER SEATING DIES SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the RIFLE PRO MICROMETER SEATING DIES by LYMAN. This product is designed to provide precision in bullet seating length while ensuring safety during its use. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always ensure you are using the die in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the die for any signs of damage or wear. Do not use if damaged.
- Use the die only for its intended purpose as specified in this guide.
- Store the die in a safe and dry location to avoid corrosion and damage.
- If you encounter any issues or have safety concerns, seek assistance immediately.

Specific Safety Precautions for Use

- Ensure that the workspace is clean and free from distractions before using the die.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves.
- Avoid wearing loose clothing or jewelry that could get caught in the equipment.
- Use the micrometer adjustment feature carefully to avoid overtightening or damaging the mechanism.
- Center the bullet properly on the case to prevent misalignment and excessive runout.
- Do not exceed the recommended bullet seating depth to avoid potential hazards.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is compatible with the RIFLE PRO MICROMETER SEATING DIES.
- Securely attach the seating die to the press according to the manufacturer's instructions.
- Adjust the die to the desired height for bullet seating.

2. Usage

- Select the bullet you intend to load and place it on the case.
- Use the micrometer adjustable seating head to set the desired bullet seating length.
- Turn the micrometer head to adjust the seating depth in small increments.
- Once the correct depth is achieved, lock the micrometer in place.
- Slowly and gently press the bullet into the case using the floating bullet seating punch.
- Inspect the seated bullet for proper alignment and depth before proceeding to the next round.

Disposal Instructions

- Dispose of any packaging materials in accordance with local waste management regulations.
- If the die is no longer usable, consider recycling it if possible. Check with local recycling centers for proper disposal methods.
- Do not dispose of the die in regular household waste if it is still functional. Instead, donate or sell to another user who may benefit from it.

Contact Information for Further Support

For any inquiries regarding safety concerns or product support, please reach out to your local distributor or the manufacturer directly. They can provide you with the necessary assistance and information.

Thank you for prioritizing safety while using the RIFLE PRO MICROMETER SEATING DIES. Your attention to these guidelines will help ensure a safe and effective reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk