

# FLIP-OPEN OBJECTIVE LENS COVERS - OBJECTIVE LENS COVER #47 2.461" (62.5MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

## Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



## Attributes

- Name: [OBJECTIVE LENS COVER #47 2.461" \(62.5MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 749001494
- Mfr. No.: 30470
- Color: Black
- End Fit: Objective
- Model Number: 2.461" (62.5MM)
- Size: 2.461
- Delivery weight: 0.023kg
- Shipping height: 33mm
- Shipping width: 97mm
- Shipping length: 150mm
- UPC: 051525304708

# Table of Contents

- Startpage
- FLIOPEN OBJECTIVE LENS COVERS Safety Instruction Guide
- About Us

# FLIPOOPEN OBJECTIVE LENS COVERS Safety Instruction Guide

## Introduction

Thank you for purchasing the FLIPOOPEN OBJECTIVE LENS COVERS. These covers are designed to protect your scope's lenses from weather, dust, and moisture during tactical and hunting situations. This guide provides essential safety information and instructions to ensure safe and effective use of the product.

## General Safety Guidelines

- Ensure that the objective lens cover is compatible with your scope by measuring the diameter of your scope eyepiece or objective.
- Always inspect the lens covers before use to ensure they are free from damage.
- Use the lens covers only for their intended purpose to avoid potential hazards.
- Keep the lens covers out of reach of children to prevent accidental use or injury.
- Report any unsafe conditions or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Do not force the cover open or closed; use gentle finger pressure to avoid damaging the mechanism.
- Ensure that the cover is securely closed when not in use to protect the lenses from environmental elements.
- Avoid exposing the lens covers to extreme temperatures or harsh chemicals, as this may compromise their integrity.
- If the lens cover becomes damaged, discontinue use immediately and replace it to ensure proper protection.

## Instructions for Installation and Usage

### 1. Measuring for Fit

- Measure the diameter of your scope eyepiece or objective to determine the correct size for the lens cover.
- Refer to the sizing chart provided by the manufacturer to confirm compatibility.

### 2. Installing the Lens Cover

- Align the lens cover with the eyepiece or objective of the scope.
- Gently press the cover onto the scope until it fits snugly.

### 3. Using the Lens Cover

- To open the cover, apply light finger pressure to the designated area.
- Allow the cover to spring up and out of the way for unobstructed viewing.
- When finished, gently press the cover back into place to protect the lens.

### 4. Regular Maintenance

- Clean the lens cover regularly with a soft, dry cloth to remove dust and debris.
- Check the mechanism periodically to ensure it is functioning properly.

## Disposal Instructions

- Dispose of the lens covers responsibly in accordance with local regulations.
- If the product is damaged beyond repair, consider recycling the materials where possible.

## Contact Information for Further Support

For any inquiries regarding safety or product information, please contact the manufacturer's customer service or visit their official website. Ensure to have your product details ready for a quicker response.

By following these guidelines, you can ensure the safe and effective use of your FLIOPEN OBJECTIVE LENS COVERS. Thank you for prioritizing safety and enjoy your hunting and tactical experiences!

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)