

ULTRA™ MICROMETER SEATER DIES - FORSTER PRODUCTS, INC. 6 XC MICROMETER SEATER DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Forster Reloading Dies are of excellent quality and provide the reloader with the ability to produce concentric rounds time and time again. Each die is manufactured from the finest quality steel carefully machined to very tight tolerances. Dies are hand polished both before and after the heat-treating process to guarantee an extra fine finish. All Forster reloading dies feature their Forster Cross Bolt Die Locking Ring that tightens the two ends of the split ring instead of tightening a screw directly into the threads of the die. The Forster Ultra Seater includes all of the features of the Forster Bench Rest Seater Die above, plus an ultra accurate micrometer adjustment. This micrometer adjustment allows you to adjust bullet seating depth from .0005 inch to .001 inch increments, and makes switching bullets easy - just dial back to your previous recorded setting. Forster Ultra Seaters make fine tuning your bullets to the lands of your rifling simple.



Attributes

- Name: [FORSTER PRODUCTS, INC. 6 XC MICROMETER SEATER DIE](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 749006854
- Mfr. No.: U00044
- Cartridge: 6 mm XC
- Diameter (in): -
- Die Style: Bullet Seating Dies
- Delivery weight: 0.499kg
- Shipping height: 56mm
- Shipping width: 130mm
- Shipping length: 216mm
- UPC: 757253999390

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [ULTRA™ MICROMETER SEATER DIES SAFETY INSTRUCTIONS](#)
- [About Us](#)

ULTRA™ MICROMETER SEATER DIES SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the ULTRA™ MICROMETER SEATER DIES by Forster Products, Inc. These highquality reloading dies are designed to help you achieve precise bullet seating for your reloading needs. This safety instruction guide provides essential information to ensure safe and effective use of the product while complying with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- **Product Safety:** Always use the ULTRA™ MICROMETER SEATER DIES as intended. Ensure that you are familiar with all safety protocols associated with reloading ammunition.
- **Enhanced Recalls:** Stay informed about product recalls. Regularly check official sources for updates regarding safety notices.
- **Online Shopping:** If purchased online, ensure that the retailer complies with safety requirements. Confirm that the product is genuine and meets EU safety standards.
- **Special Consumer Focus:** Keep the dies out of reach of children and vulnerable individuals. Ensure that only trained adults handle reloading equipment.
- **EU Contact Point:** For any safety inquiries, refer to the EU contact points provided by your retailer or manufacturer.
- **Rapid Alerts:** Be proactive in checking the EU's Safety Gate platform for updates on product safety and potential hazards.

Specific Safety Precautions for Use

- **Read the Manual:** Thoroughly read the product manual before use. Familiarize yourself with all features and operational guidelines.
- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses and gloves, when handling reloading dies and ammunition components.
- **Work Environment:** Ensure that your workspace is clean, welllit, and free from distractions. Use a sturdy, stable workbench.
- **Avoid Overloading:** Do not exceed the recommended specifications for bullet seating depth or pressure. Follow guidelines for your specific cartridge.
- **Regular Inspection:** Inspect the dies regularly for wear or damage. Do not use damaged dies, as they may cause accidents or injuries.
- **Proper Handling:** Handle all components with care. Avoid dropping or mishandling dies, as this may affect their precision and safety.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure your reloading press is securely mounted and stable.
 2. Remove the die from its packaging and inspect it for any visible defects.
 3. Thread the ULTRA™ MICROMETER SEATER DIE into the reloading press according to the manufacturer's instructions.
 4. Tighten the die securely using the Forster Cross Bolt Die Locking Ring to prevent movement during use.
- **Usage:**

1. Set the micrometer adjustment to your desired bullet seating depth. Adjust in increments of .0005 inch to .001 inch as needed.
2. Insert the bullet into the die and ensure it is properly seated before proceeding.
3. Perform test seating with dummy rounds to verify the accuracy of your settings.
4. Once satisfied with the results, proceed with reloading your ammunition according to standard practices.

Disposal Instructions

- **Disposal of Dies:** If the dies are damaged or no longer usable, dispose of them in accordance with local regulations for metal recycling.
- **Ammunition Components:** Dispose of any unused or defective ammunition components responsibly. Follow local laws for hazardous waste disposal if applicable.

Contact Information for Further Support

For any questions or concerns regarding the ULTRA™ MICROMETER SEATER DIES, please refer to the contact information provided by your retailer or directly from Forster Products, Inc. Ensure that you have the product details on hand for quicker assistance.

By following these safety instructions, you can ensure a safe and effective reloading experience with the ULTRA™ MICROMETER SEATER DIES. Always prioritize safety and stay informed about best practices in the reloading community.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk