

# ULTRA™ MICROMETER SEATER DIES - FORSTER PRODUCTS, INC. 300 AAC BLACKOUT MICROMETER SEATER DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Forster Reloading Dies are of excellent quality and provide the reloader with the ability to produce concentric rounds time and time again. Each die is manufactured from the finest quality steel carefully machined to very tight tolerances. Dies are hand polished both before and after the heat-treating process to guarantee an extra fine finish. All Forster reloading dies feature their Forster Cross Bolt Die Locking Ring that tightens the two ends of the split ring instead of tightening a screw directly into the threads of the die. The Forster Ultra Seater includes all of the features of the Forster Bench Rest Seater Die above, plus an ultra accurate micrometer adjustment. This micrometer adjustment allows you to adjust bullet seating depth from .0005 inch to .001 inch increments, and makes switching bullets easy - just dial back to your previous recorded setting. Forster Ultra Seaters make fine tuning your bullets to the lands of your rifling simple.



## Attributes

- Name: [FORSTER PRODUCTS, INC. 300 AAC BLACKOUT MICROMETER SEATER DIE](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 749012800
- Mfr. No.: U00099
- Cartridge: 300 AAC Blackout
- Diameter (in): -
- Die Style: Bullet Seating Dies
- Delivery weight: 0.408kg
- Shipping height: 53mm
- Shipping width: 130mm
- Shipping length: 218mm
- UPC: 757253996214

## Item details

Made in USA

# Table of Contents

- Startpage
- ULTRA™ MICROMETER SEATER DIES SAFETY INSTRUCTION GUIDE
- About Us

# ULTRA™ MICROMETER SEATER DIES SAFETY INSTRUCTION GUIDE

## Introduction

Thank you for choosing the ULTRA™ MICROMETER SEATER DIES by Forster Products, Inc. This guide provides essential safety instructions to ensure the safe and effective use of your reloading dies. Please read this guide carefully before using the product.

## General Safety Guidelines

- Ensure that you are familiar with the reloading process and local laws regarding reloading ammunition.
- Always wear appropriate safety gear, including safety glasses and gloves, while handling reloading equipment.
- Keep the reloading area clean and organized to prevent accidents.
- Store reloading dies and components in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your dies for wear and damage. Do not use damaged equipment.
- Follow all manufacturer instructions and guidelines included with your reloading equipment.

## Specific Safety Precautions for Use

- Use only compatible cartridges with the ULTRA™ MICROMETER SEATER DIES. This product is specifically designed for the 300 AAC Blackout cartridge.
- Avoid overtightening the locking ring, as this may damage the die or affect its performance.
- When adjusting the micrometer, make small incremental changes to avoid excessive pressure on the bullet.
- Always ensure that the die is securely mounted in the reloading press before use.
- Never attempt to modify the die or its components.
- Be aware of your surroundings and ensure that no unauthorized persons are present when reloading.

## Instructions for Installation and Usage

### 1. Installation:

- Securely mount the ULTRA™ MICROMETER SEATER DIE in your reloading press according to the manufacturer's instructions.
- Ensure that the die is properly aligned with the press and locked in place.

### 2. Usage:

- Set the micrometer adjustment to your desired bullet seating depth. The adjustment range is from .0005 inch to .001 inch increments.
- Insert the cartridge case into the press and ensure it is positioned correctly under the die.
- Place the bullet on top of the cartridge case.
- Pull the handle of the press to seat the bullet into the case.
- After seating, check the bullet depth using a caliper to ensure it meets your specifications.
- If you need to change the bullet type, simply dial back to your previous recorded setting on the micrometer for consistent seating depth.

## **Disposal Instructions**

- Dispose of any used or damaged reloading dies and components in accordance with local regulations.
- Do not dispose of reloading materials in regular household waste. Check with local authorities for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the ULTRA™ MICROMETER SEATER DIES, please refer to the contact information provided with the product packaging or visit the manufacturer's website for assistance.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable reloading experience with your ULTRA™ MICROMETER SEATER DIES. Thank you for your attention to safety!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)