

ULTRA™ MICROMETER SEATER DIES - FORSTER PRODUCTS, INC.

7.62X54R MICROMETER SEATER DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Forster Reloading Dies are of excellent quality and provide the reloader with the ability to produce concentric rounds time and time again. Each die is manufactured from the finest quality steel carefully machined to very tight tolerances. Dies are hand polished both before and after the heat-treating process to guarantee an extra fine finish. All Forster reloading dies feature their Forster Cross Bolt Die Locking Ring that tightens the two ends of the split ring instead of tightening a screw directly into the threads of the die. The Forster Ultra Seater includes all of the features of the Forster Bench Rest Seater Die above, plus an ultra accurate micrometer adjustment. This micrometer adjustment allows you to adjust bullet seating depth from .0005 inch to .001 inch increments, and makes switching bullets easy - just dial back to your previous recorded setting. Forster Ultra Seaters make fine tuning your bullets to the lands of your rifling simple.



Attributes

- Name: [FORSTER PRODUCTS, INC. 7.62X54R MICROMETER SEATER DIE](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 749012948
- Mfr. No.: U00080
- Cartridge: 7.62 x 54 mm Russian
- Diameter (in): -
- Die Style: Bullet Seating Dies
- Delivery weight: 0.476kg
- Shipping height: 53mm
- Shipping width: 130mm
- Shipping length: 216mm
- UPC: 757253006289

Item details

Made in USA

Table of Contents

- Startpage
- ULTRA™ MICROMETER SEATER DIES SAFETY INSTRUCTION GUIDE
- About Us

ULTRA™ MICROMETER SEATER DIES SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the ULTRA™ MICROMETER SEATER DIES from Forster Products, Inc. This guide provides essential safety instructions and information to ensure safe and effective use of your reloading dies. Please read this guide carefully before use, and keep it for future reference.

General Safety Guidelines

- Ensure that all users are familiar with the basic principles of reloading and firearm safety.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading equipment.
- Keep reloading dies and components out of reach of children and unauthorized individuals.
- Store the dies in a dry, cool place to prevent rust and damage.
- Regularly inspect your reloading dies for any signs of wear or damage. Do not use damaged equipment.
- Follow all local laws and regulations regarding reloading and firearm use.

Specific Safety Precautions for Use

- Always doublecheck the compatibility of the die with the specific cartridge you are reloading (7.62 x 54 mm Russian).
- Ensure that the reloading press is securely mounted and stable before use.
- Do not exceed the recommended load data provided by reliable sources.
- Use a reliable scale and measuring tools to ensure accurate powder and bullet measurements.
- Never leave reloading equipment unattended while in use.
- In case of any malfunction or unusual noise during operation, stop using the equipment immediately and inspect it for issues.

Instructions for Installation and Usage

Installation

1. Mounting the Die:

- Ensure the reloading press is turned off and unplugged.
- Securely mount the ULTRA™ MICROMETER SEATER DIE into the reloading press according to the manufacturer's instructions.
- Tighten the Forster Cross Bolt Die Locking Ring to ensure the die is firmly in place.

2. Adjusting the Micrometer:

- Use the micrometer adjustment feature to set the desired bullet seating depth.
- To adjust, turn the micrometer knob to increase or decrease the seating depth in increments of .0005 inch to .001 inch.
- Always make minor adjustments and test with a dummy round to confirm the correct seating depth.

Usage

1. Preparation:

- Inspect all components, including brass, bullets, and powder, before starting the reloading process.
- Ensure your workspace is clean and organized.

2. **Reloading Process:**

- Follow standard reloading procedures: resize the brass, charge the case with powder, and seat the bullet using the ULTRA™ MICROMETER SEATER DIE.
- After seating, visually inspect the cartridge for proper bullet seating and overall quality.
- Store completed cartridges in a safe and organized manner.

3. **PostUse Care:**

- Clean the die after each use to remove any residue or debris.
- Store the die in its original packaging or a protective case to prevent damage.

Disposal Instructions

- Dispose of any unused or expired reloading components in accordance with local regulations.
- Do not dispose of reloading waste in regular household trash. Check with local waste management for proper disposal methods.
- Ensure that any hazardous materials are handled and disposed of according to safety guidelines.

Contact Information for Further Support

For any questions or concerns regarding the ULTRA™ MICROMETER SEATER DIES, please refer to the manufacturer's website or contact their customer support for assistance.

By following these safety instructions, you can ensure a safe and effective reloading experience with your ULTRA™ MICROMETER SEATER DIES. Always prioritize safety and compliance with local laws while enjoying the reloading process.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk