

MICRO-ADJUST BULLET SEATERS - SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 260 REMINGTON

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

We gathered our customers ideas and reloading experience with hand dies, and partnered with the experts who make them, to introduce the new Sinclair/L.E. Wilson Micro-Adjust Bullet Seater. It features easy-adjust seating depth capabilities with a simple turn of the die body. Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters are detent-bearing driven with positive "click" increments of .0005" for fast, accurate bullet seating depth adjustments. Here are the details of construction: Each seater stem is custom fitted to the seater body ensuring close tolerance fit Precision-cut threads allow bullet seating depth adjustment in .0005" increments Graduated scale for repeated use with different bullets and seating depths Micro-Adjust "clicks" via stainless springs and stainless ball bearings Constructed of 416 Stainless Steel with precise, laser-etched adjustment scale Made in the USA by L.E. Wilson with 85 years of inline die experience We feel these dies are the finest available in terms of quality, construction, and performance.



Attributes

- Name: [SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 260 REMINGTON](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749014511
- Mfr. No.: SIN-260R
- Cartridge: 260 Remington
- Die Style: Bullet Seating Dies
- Delivery weight: 0.483kg

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for MICROADJUST BULLET SEATERS
- About Us

Safety Instruction Guide for MICROADJUST BULLET SEATERS

Introduction

Thank you for choosing the Sinclair International MicroAdjust Bullet Seater for your reloading needs. This product is designed to provide precision and ease of use when seating bullets. To ensure your safety and the proper functioning of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that you are familiar with the operation of reloading equipment before using this product.
- Always handle reloading components and equipment with care to avoid accidents.
- Store all reloading supplies in a secure location, out of reach of children and vulnerable individuals.
- Regularly inspect the bullet seater for any signs of wear or damage before each use.
- Follow all manufacturer instructions for the safe use of the bullet seater.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses, when operating the bullet seater.
- Do not use the bullet seater with damaged or defective components.
- Ensure that the work area is clean and free from clutter to avoid accidents.
- Keep fingers and hands clear of the bullet seating area during operation.
- Never exceed the recommended bullet seating depth as specified by the bullet manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure that the bullet seater is compatible with your reloading press.
- Securely attach the bullet seater to the reloading press according to the manufacturer's instructions.
- Doublecheck that all connections are tight and secure before use.

2. Usage:

- Adjust the seating depth by turning the die body as indicated in the product instructions.
- Use the graduated scale for repeated use with different bullets and seating depths.
- Make adjustments in increments of .0005 inches for precise bullet seating.
- After making adjustments, perform a test seating with a dummy round to ensure proper operation.

Disposal Instructions

- Dispose of any defective or damaged bullet seaters in accordance with local regulations for hazardous waste.
- Recycle materials whenever possible to minimize environmental impact.
- Follow local guidelines for the disposal of reloading components and supplies.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Sinclair International MicroAdjust Bullet Seater,

please reach out to your local distributor or refer to the manufacturer's website for further assistance.

Conclusion

By following these safety instructions, you can ensure a safe and efficient reloading experience with your Sinclair International MicroAdjust Bullet Seater. Always prioritize safety and stay informed about best practices in reloading. Thank you for your commitment to safe reloading practices.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu