

MICROMETER SEATER DIES - WHIDDEN GUNWORKS 6MM SLR BULLET SEATER DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

For precise, consistent OAL handloads, the internals of the Whidden Seater Die are designed to keep your rounds Round. Inside the die is a floating sleeve system helps to improve concentricity - a must for repeatable precision. The Micrometer Adjustable Seating Die has flutes for precise hand adjustment at the loading bench. The depth increments are easily read and will stay that way for years of use.



Attributes

- Name: [WHIDDEN GUNWORKS 6MM SLR BULLET SEATER DIE](#)
- Manufacturer: [WHIDDEN GUNWORKS](#)
- Product no.: 749016223
- Mfr. No.: MSD-S-0-006SLR-000
- Cartridge: 6 mm SLR
- Die Style: Seater Die
- Delivery weight: 0.425kg

Item details

Made in USA

Table of Contents

- Startpage
- MICROMETER SEATER DIES WHIDDEN GUNWORKS 6MM SLR BULLET SEATER DIE Safety Instruction Guide
- About Us

MICROMETER SEATER DIES WHIDDEN GUNWORKS 6MM SLR BULLET SEATER DIE Safety Instruction Guide

Introduction

Thank you for choosing the Whidden Gunworks 6mm SLR Bullet Seater Die. This product is designed for precision handloading, ensuring consistent overall length (OAL) for your ammunition. To ensure safe and effective use of this product, please read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Ensure that all components are in good condition before use.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the work area clean and organized to prevent accidents.
- Ensure that children and pets are kept away from the reloading area.
- Familiarize yourself with the specific features and functions of the Micrometer Seater Die before use.
- Regularly check for updates on product recalls and safety alerts via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Do not exceed the recommended load data provided by reputable sources.
- Always verify that the die is properly secured in the reloading press before use.
- Avoid using the die with damaged or worn components.
- Be cautious of the potential for lead exposure; wash hands thoroughly after handling ammunition components.
- Store the die in a secure location when not in use to prevent unauthorized access.

Instructions for Installation and Usage

1. Installation:

- Secure the Micrometer Seater Die into the reloading press according to the manufacturer's instructions.
- Ensure that the die is tightened properly to prevent movement during operation.

2. Usage:

- Adjust the micrometer setting to the desired depth based on your load specifications.
- Use the floating sleeve system to ensure concentricity while seating the bullet.
- Perform a test run with a dummy round to verify the seating depth before loading live ammunition.
- Monitor the seating process closely to ensure consistent results.

Disposal Instructions

- Dispose of any unused or expired components in accordance with local regulations.
- Do not discard ammunition or reloading components in regular waste; follow specific hazardous waste disposal guidelines where applicable.

Contact Information for Further Support

For any inquiries or further assistance regarding the Whidden Gunworks Micrometer Seater Die, please refer to the product packaging or visit the manufacturer's website for contact details.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Whidden Gunworks 6mm SLR Bullet Seater Die. Always prioritize safety and stay informed about best practices in ammunition reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk