

STAINLESS STEEL LOCK NUT - L.E. WILSON STAINLESS STEEL LOCK NUT W/SET SCREW

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Manufactured by L.E. Wilson, this stainless steel lock nut with set screw allows users to lock their reloading dies in place so they can be removed from the press and reinserted without having to re-adjust depth. Fits 7/8"-14 threads which are standard on most reloading dies.



Attributes

- Name: [L.E. WILSON STAINLESS STEEL LOCK NUT W/SET SCREW](#)
- Manufacturer: [L.E. WILSON](#)
- Product no.: 749016627
- Mfr. No.: FLP-SSNT
- Delivery weight: 0.005kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 815145029737

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for L.E. Wilson Stainless Steel Lock Nut with Set Screw
- About Us

Safety Instruction Guide for L.E. Wilson Stainless Steel Lock Nut with Set Screw

Introduction

Thank you for choosing the L.E. Wilson Stainless Steel Lock Nut with Set Screw. This product is designed to securely lock your reloading dies in place, allowing for easy removal and reinsertion without the need for readjustment. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure you are familiar with the operation of your reloading press before using the lock nut.
- Always wear appropriate safety gear, including safety glasses, when working with reloading equipment.
- Keep the lock nut and reloading dies out of reach of children and vulnerable individuals.
- Regularly inspect the lock nut for any signs of wear or damage before each use.
- If you notice any defects or if the lock nut does not function as intended, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always ensure that the lock nut is securely tightened before starting your reloading process to prevent any accidental loosening.
- Do not use excessive force when tightening the lock nut, as this may lead to damage.
- Avoid using the lock nut with reloading dies that are not compatible with 7/8"14 threads.
- Do not modify the lock nut or attempt to repair it if damaged; replace it with a new one.
- Be cautious when handling tools and equipment during reloading to prevent injuries.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged.
- Select the appropriate reloading die that fits the 7/8"14 threads.
- Screw the reloading die into the press until it is snug.
- Place the stainless steel lock nut onto the reloading die and handtighten it securely.
- Use a wrench to tighten the lock nut further, ensuring it is secure but not overtightened.

2. Usage:

- Once the lock nut is installed, you can proceed with your reloading process as per your specific instructions.
- If you need to remove the reloading die, simply loosen the lock nut and unscrew the die from the press.
- To reinsert the die, follow the installation steps again, ensuring the lock nut is tightened securely.

Disposal Instructions

- Dispose of the lock nut in accordance with local regulations for metal waste.
- Do not dispose of the lock nut in regular household waste.
- If the lock nut is damaged or no longer usable, consider recycling it at a designated facility.

Contact Information for Further Support

For any inquiries regarding safety or performance of the L.E. Wilson Stainless Steel Lock Nut with Set Screw, please refer to the manufacturer's contact information provided on the packaging or product documentation.

By following these safety instructions, you will help ensure a safe and effective reloading experience. Always prioritize safety and stay informed about the proper use of your equipment.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk