

# BRASS MINIMUM DIMENSION CHAMBER GAGES - L.E. WILSON 223 REMINGTON BRASS MINIMUM CHAMBER GAGE

[Reloading](#) > [Measuring Tools](#) > [Case Gauges & Headspace Tools](#)

Ever wonder if your reloads meet SAAMI minimum chamber dimensions? Then this is the gage for you. Min Dimensions Gages are made to SAAMI specifications for Min Chamber. SAAMI Min Chamber specs are slightly LARGER than Max Cartridge. The purpose of this gage is to check your reloaded rounds to see if they meet Min Chamber Specs. Therefore, if your rounds do not enter the Gage, then this is pointing to an issue with your reloaded round against SAAMI specifications. On the other hand, if your rounds DO enter the Gage, but DO NOT chamber in your gun. This points to you having a very tight chambered gun and would assume either an improperly cut reamer or a chamber that was cut below Min Chamber Dimension headspace. This does NOT mean that your round will not chamber in your specific gun's chamber. This only means the round DOES NOT meet SAAMI Min Chamber dimensions and is telling you to take another look before deciding that your round is good to fire.



## Attributes

- Name: [L.E. WILSON 223 REMINGTON BRASS MINIMUM CHAMBER GAGE](#)
- Manufacturer: [L.E. WILSON](#)
- Product no.: 749018708
- Mfr. No.: MDG-223R
- Cartridge: 223 Remington
- Delivery weight: 0.238kg
- Shipping height: 38mm
- Shipping width: 32mm
- Shipping length: 89mm
- UPC: 815145028679

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 223 REMINGTON
- About Us

# Safety Instruction Guide for BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 223 REMINGTON

## Introduction

Thank you for choosing the BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 223 REMINGTON. This guide provides important safety information to ensure the proper use and handling of your gage. Please read this document carefully to understand how to use the product safely and effectively.

## General Safety Guidelines

- Ensure that the gage is used only for its intended purpose, which is to check reloaded rounds against SAAMI minimum chamber specifications.
- Always handle the gage with care to avoid damage and ensure accurate readings.
- Keep the gage out of reach of children and vulnerable individuals.
- Regularly inspect the gage for any signs of wear or damage before use.
- If you suspect that the gage is not functioning correctly, discontinue use and seek assistance.

## Specific Safety Precautions for Use

- **Check Compatibility:** Ensure that your reloaded rounds are compatible with the gage specifications before use.
- **Proper Handling:** Always hold the gage by its body and avoid touching the measuring area to prevent contamination.
- **Inspect Rounds:** Before using the gage, visually inspect your reloaded rounds for any visible defects or abnormalities.
- **Follow SAAMI Guidelines:** Familiarize yourself with SAAMI minimum chamber specifications to understand the acceptable dimensions for your reloaded rounds.
- **Tight Chambers:** If your rounds do not chamber in your gun after passing through the gage, it may indicate a very tight chamber. Consult a qualified gunsmith for further evaluation.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure your workspace is clean and welllit.
- Gather all necessary materials, including the gage and your reloaded rounds.

### 2. Using the Gage:

- Insert the reloaded round into the gage.
- Ensure that the round is fully seated within the gage.
- If the round does not enter the gage, it does not meet the minimum chamber specifications.
- If the round enters but does not chamber in your firearm, it may indicate a tight chamber.

### 3. PostUse Care:

- Clean the gage after each use to maintain accuracy and longevity.
- Store the gage in a protective case or designated area to prevent damage.

## **Disposal Instructions**

- Dispose of the gage according to local regulations regarding electronic and metal waste.
- Do not dispose of the gage in regular household waste.
- If the gage is damaged beyond repair, consult local waste management facilities for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the use of the BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 223 REMINGTON, please refer to the manufacturer's website or contact customer support through the provided channels. Always ensure you have the product details ready when seeking assistance.

By following these guidelines and instructions, you can ensure the safe and effective use of your BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 223 REMINGTON. Thank you for your attention to safety.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)